


# PCG-SR17/SR17K

## SERVICE MANUAL

*US Model  
Canadian Model*



Illust : PCG-SR17K



Confidential

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

NOTEBOOK COMPUTER

**SONY®**

Sony and VAIO are trademarks of Sony. Intel logo and Intel Inside logo are registered trademarks of Intel Corporation. Pentium MMX is a trademark of Intel Corporation. Microsoft, MS-DOS, Windows, the Windows 95 and Windows 98 logo are trademarks of Microsoft Corporation.

Caution Markings for Lithium/Ion Battery - The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

**CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

**CAUTION:** The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F) or incinerate.

Dispose of used battery promptly.  
Keep away from children.

**CAUTION:** Changing the back up battery.

- Overcharging, short circuiting, reverse charging, mutilation or incineration of the cells must be avoided to prevent one or more of the following occurrences; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection.

### 1. Obey precautionary markings and instructions

Labels and stamps on the cabinet, chassis, and components identify areas requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

## 2. Use designated parts only

The set's components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the  $\triangle$  mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions: be certain to use only the designated components.

### 3. Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

#### 4. Inspect after completing service

After servicing, inspect to make sure that all screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

## 5. When replacing chip components...


Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

## 6. When handling flexible print boards...

- The temperature of the soldering-iron tip should be about 270°C.
- Do not apply the tip more than three times to the same pattern.
- Handle patterns with care: never apply force.

**Caution:** Remember that hard disk drives are easily damaged by vibration. Always handle with care.

**ATTENTION AU COMPOSANT AYANT RAPPORT  
À LA SÉCURITÉ!**

**LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE  SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.**

PCG-SR17/SR17K (UC)

## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>SECTION 1</b>		
<b>CHAPTER 1. OPERATION</b>		
1-1.	VAIO Notebook User Guide .....	1-1
<b>SECTION 2</b>		
<b>CHAPTER 1. REMOVAL</b>		
1-1.	Flowchart .....	1-1
1-2.	Main Electrical Parts Location Diagram .....	1-1
1-3.	Removal .....	1-2
1.	Keyboard Unit, Parm Assy .....	1-2
2.	Touch pad, Speaker, SWX-61 Board .....	1-2
3.	HDD .....	1-3
4.	Speaker, IFX-125 Board .....	1-3
5.	DC Fan, Cooling .....	1-4
6.	Main Board Assy .....	1-4
7.	MBX-44 Board, IFX-124 Board, DDC-3 Board V/L Rechargeable Battery .....	1-5
8.	CNX-107 Board .....	1-5
9.	Display Assy .....	1-6
10.	Housing (Bezel) Assy .....	1-6
11.	Inverter Unit, ANL-24 Board, Microphone, LCD Assy .....	1-7
	(to 1-7)	
<b>CHAPTER 2. SELF DIAGNOSTICS</b>		
2-1.	Precautions .....	2-1
2-2.	Necessary Tools .....	2-1
2-3.	Starting up the Service Diagnostics .....	2-1
2-4.	Outline of Service Diagnostics Functions .....	2-2
2-5.	Inspecting Windows .....	2-5
	(to 2-5)	
<b>CHAPTER 3. BLOCK DIAGRAM</b> .....		
	(to 3-2)	
<b>CHAPTER 4. FRAME HARNESS DIAGRAM</b> .....		
	(to 4-2)	
<b>CHAPTER 5. EXPLODED VIEWS AND PARTS LIST</b>		
5-1.	Main Section .....	5-1
5-2.	LCD Section – Made by TS – .....	5-3
	(to 5-4)	
<ul style="list-style-type: none"> <li>Abbreviations</li> <li>UC : US model / Canadian model</li> </ul>		

**1-1. VAIO Notebook User Guide**

**SONY®**



*VAIO Notebook*  
**User Guide**

*PCG-SR17*  
*PCG-SR17K*

[www.sony.com](http://www.sony.com)

---

## Notice to Users

© 2000 Sony Electronics Inc. All rights reserved. This manual and the software described herein, in whole or in part, may not be reproduced, translated, or reduced to any machine-readable form without prior written approval.

SONY ELECTRONICS INC. PROVIDES NO WARRANTY WITH REGARD TO THIS MANUAL, THE SOFTWARE, OR OTHER INFORMATION CONTAINED HEREIN AND HEREBY EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE WITH REGARD TO THIS MANUAL, THE SOFTWARE, OR SUCH OTHER INFORMATION. IN NO EVENT SHALL SONY ELECTRONICS INC. BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, WHETHER BASED ON TORT, CONTRACT, OR OTHERWISE, ARISING OUT OF OR IN CONNECTION WITH THIS MANUAL, THE SOFTWARE, OR OTHER INFORMATION CONTAINED HEREIN OR THE USE THEREOF.

Sony Electronics Inc. reserves the right to make any modification to this manual or the information contained herein at any time without notice. The software described herein is governed by the terms of a separate user license agreement.

This product contains software owned by Sony and licensed by third parties. Use of such software is subject to the terms and conditions of license agreements enclosed with this product. Some of the software may not be transported or used outside the United States. Software specifications are subject to change without notice and may not necessarily be identical to current retail versions.

Updates and additions to software may require an additional charge. Subscriptions to online service providers may require a fee and credit card information. Financial services may require prior arrangements with participating financial institutions.



As an ENERGY STAR Partner, Sony Corporation has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

The International ENERGY STAR Office Equipment Program is an international program that promotes energy saving through the use of computers and other office equipment. The program backs the development and dissemination of products with functions that effectively reduce energy consumption. It is an open system in which business proprietors can participate voluntarily. The targeted products are office equipment such as computers, displays, printers, facsimiles and copiers. Their standards and logos are uniform among participating nations. ENERGY STAR is a U.S. registered mark.

Sony, i.LINK, Jog Dial, Mavica, Memory Stick, the Memory Stick logo, MG Memory Stick, DV Gate, Media Bar, Handycam, MovieShaker, PictureGear, VAIO and the VAIO logo are trademarks of Sony Corporation. Microsoft® Windows Me, Windows, Windows Media, Windows NT, and the Windows logo are trademarks of Microsoft Corporation. Intel, SpeedStep, and Pentium are trademarks of Intel Corporation. PS/2 is a registered trademark of IBM.

All other trademarks are trademarks of their respective owners.

## Owner's Record

The model number and serial number are located on the bottom of your Sony notebook. Record the serial number in the space provided here. Refer to the model and serial number when you call your Sony Service Center.

Model Number: PCG-321A, PCG-321Z

Serial Number: \_\_\_\_\_

## Safety Information

### WARNING

To prevent fire or shock hazard, do not expose your notebook to rain or moisture. To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

- ☐ Never install modem or telephone wiring during a lightning storm.
- ☐ Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- ☐ Never touch uninsulated telephone wire or terminals unless the telephone line has been disconnected at the network interface.
- ☐ Use caution when installing or modifying telephone lines.
- ☐ Avoid using the modem during an electrical storm.
- ☐ Do not use the modem or a telephone to report a gas leak in the vicinity of the leak.

- ☐ A socket outlet should be as close as possible to the unit and easily accessible.



**The use of optical instruments with this product will increase eye hazard. As the laser beam used in this product is harmful to the eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.**

**DANGER: Visible and invisible laser radiation when open. Avoid direct exposure to beam.**

**Caution: To reduce the risk of fire, use only No. 26 AWG or larger telecommunication line cord**

### Avertissement

Pour prévenir tout risque d'incendie ou d'électrocution, garder cet appareil à l'abri de la pluie et de l'humidité. Pour prévenir tout risque d'électrocution, ne pas ouvrir le châssis de cet appareil et ne confier son entretien qu'à une personne qualifiée.

- ☐ Ne jamais effectuer l'installation de fil modem ou téléphone durant un orage électrique.
- ☐ Ne jamais effectuer l'installation d'une prise téléphonique dans un endroit mouillé à moins que la prise soit conçue à cet effet.
- ☐ Ne jamais toucher un fil téléphonique à découvert ou un terminal à moins que la ligne téléphonique n'ait été débranché de l'interface réseau.

- ❑ Soyez très prudent lorsque vous installez ou modifiez les lignes téléphoniques.
- ❑ Évitez d'utiliser le modem durant un orage électrique.
- ❑ N'utilisez pas le modem ni le téléphone pour prévenir d'une fuite de gaz si vous êtes près de la fuite.
- ❑ L'appareil doit être le plus près possible d'une prise murale pour en faciliter l'accès.



**Comme le faisceau laser utilisé par cet appareil est dangereux pour les yeux, ne tentez pas de démonter le boîtier. Confiez l'entretien de cet appareil exclusivement au personnel qualifié. Adressez-vous à un agent de service qualifié.**

**DANGER : Radiation laser visible et invisible si ouvert. Evitez l'exposition directe au faisceau.**

**Attention : Afin de réduire les risques d'incendie, n'utilisez qu'un cordon de communication NO. 26 AWG ou plus gros.**

## Regulatory Information

If you have any questions about this product, you can reach the Sony Customer Information Service Center at 1-888-4SONYPC; or write to the Sony Customer Information Service Center at 12451 Gateway Blvd., Ft. Meyers, FL 33913, or find Sony Customer Service on the Web at: <http://www.sony.com/pcsupport>.

## Declaration of Conformity

Trade Name:	SONY
Model No.:	PCG-321A, PCG-3212
Responsible Party:	Sony Electronics Inc.
Address:	1 Sony Drive Park Ridge, NJ 07656
Telephone:	201-930-6972

This phone number is for FCC-related matters only.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ❑ Reorient or relocate the receiving antenna.
- ❑ Increase the separation between the equipment and the receiver.
- ❑ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ❑ Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Only peripherals (computer input/output devices, terminals, printers, etc.) that comply with FCC Class B limits may be attached to this computer product. Operation with noncompliant peripherals is likely to result in interference to radio and television reception.

All cables used to connect peripherals must be shielded and grounded. Operation with cables, connected to peripherals, that are not shielded and grounded, may result in interference to radio and television reception.

## **FCC Part 68**

This equipment complies with Part 68 of the FCC rules. On the bottom of this equipment is a label that contains, among other information, the FCC Ringer Equivalence Number (REN) for this equipment. If requested, this information must be provided to the telephone company.

This modem uses the USOC RJ-11 telephone jack.

The REN is used to determine the quantity of devices which may be connected to the

telephone line. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of the RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to the line, as determined by the total RENs, contact the telephone company to determine the maximum REN for the calling area.

If the terminal equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operations of the equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, you can reach the Sony Customer Information Service Center at 1-888-4SONYPC; or write to the Sony Customer Information Service Center at 12451 Gateway Blvd., Ft. Myers, FL 33913, or find Sony Customer Service on the web at <http://www.sony.com/pcsupport>.

Repair of this equipment should be made only by a Sony Service Center or Sony authorized agent.

This equipment cannot be used on public coin service provided by the telephone company. Connection to Party Line Service is subject to state and possible provincial tariffs. (Contact the state or provincial utility service commission, public service commission, or corporation commission for information.)



---

## ***Telephone Consumer Protection Act of 1991 (United States)***

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device to send any message via a telephone facsimile machine unless such message clearly contains, in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business, other entity, or individual sending the message, and the telephone number of the sending machine or such business, other entity, or individual.

In order to program this information into your facsimile machine, see your fax software documentation.

## ***Telephone Consumer Guidelines (Canada)***

Please refer to your telephone directory under 'Privacy Issues' and/or 'Terms of Service.' For more detailed information, please contact:

CRTC


Terrasses de la Chaudière, Tour centrale  
1 promenade du Portage, 5 étage Hull PQ K1A 0N2.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## ***DISPOSAL OF LITHIUM ION BATTERY***

You can return your unwanted lithium ion batteries to your nearest Sony Service Center or Factory Service Center.

 In some areas the disposal of lithium ion batteries in household or business trash may be prohibited.

For the Sony Service Center nearest you, call 1-888-476-6972 in the United States or 1-800-961-7669 in Canada.



**Do not handle damaged or leaking lithium ion batteries.**

**Ne pas manipuler les batteries au lithium-ion qui fuient ou sont endommagées.**



**Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.**

**Une batterie non conforme présente un danger d'explosion. La remplacer seulement par une batterie identique ou de type équivalent recommandé par le fabricant. Évacuer les batteries usées selon les directives du fabricant.**



**The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 212°F (100°C) or incinerate. Dispose of used battery promptly. Keep away from children.**

**La manutention incorrecte du module de batterie de cet appareil présente un risque d'incendie ou de brûlures chimiques. Ne pas démonter, incinérer ou exposer à une température de plus de 100°C. Évacuer promptement la batterie usée. Garder hors de portée des enfants.**

## INDUSTRY CANADA NOTICE

NOTICE: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection.

The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Equipment malfunctions or any repairs or alterations made by the user to this equipment may give the telecommunications company cause to request that the user disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

CAUTION: Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority, or electrician, as appropriate.

NOTICE: The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5. The Ringer Equivalence Number for this equipment is 1.1.

## AVIS DE L'INDUSTRIE CANADA

AVIS: L'étiquette d'Industrie Canada identifie le matériel homologué.

Cette étiquette certifie que le matériel est conforme aux normes de protection, d'exploitation et de sécurité des réseaux de télécommunications, comme le prescrivent les documents concernant les exigences techniques relatives au matériel terminal. Le Ministère n'assure toutefois pas que le matériel fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer ce matériel, l'utilisateur doit s'assurer qu'il est permis de le raccorder aux

---

installations de l'entreprise locale de télécommunication. Le matériel doit également être installé en suivant une méthode acceptée de raccordement. L'abonné ne doit pas oublier qu'il est possible que la conformité aux conditions énoncées ci-dessus n'empêche pas la dégradation du service dans certaines situations.

Les réparations de matériel homologué doivent être coordonnées par un représentant désigné par le fournisseur. L'entreprise de télécommunications peut demander à l'utilisateur de débrancher un appareil à la suite de réparations ou de modifications effectuées par l'utilisateur ou à cause de mauvais fonctionnement.

Pour sa propre protection, l'utilisateur doit s'assurer que tous les fils de mise à la terre de la source d'énergie électrique, des lignes téléphoniques et des canalisations d'eau métalliques, s'il y en a, sont raccordés ensemble. Cette précaution est particulièrement importante dans les régions rurales.

Avertissement: L'utilisateur ne doit pas tenter de faire ces raccordements lui-même; il doit avoir recours à un service d'inspection des installations électriques, ou à un électricien, selon le cas.

AVIS: L'indice d'équivalence de la sonnerie (IES) assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface.

La terminaison d'une interface téléphonique peut consister en une combinaison de quelques dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

L'indice d'équivalence de la sonnerie de ce matériel est de 1.1.

# Contents

<b>Welcome.....</b>	<b>13</b>
Features .....	13
Unpacking Your Notebook .....	14
Ergonomic Considerations .....	16
 <b>Setting Up Your VAIO® Notebook .....</b>	 <b>21</b>
Locating Controls and Connectors .....	21
Connecting a Power Source .....	25
Starting Your Computer .....	31
Shutting Down Your Computer .....	32
 <b>Using Your VAIO® Notebook .....</b>	 <b>33</b>
Using the Keyboard.....	33
Using the Touchpad .....	38
Using a Floppy Disk Drive (optional).....	40
Connecting the CD/DVD Drive (optional) .....	43
Using PC Cards .....	47
Using Smart Connect .....	50
i.LINK® Interface .....	51
Connecting an i.LINK® device.....	51
VAIO Action Setup.....	54
The Jog Dial™ Control .....	54

Using <b>Memory Stick®</b> Media .....	57
Using Power Saving Modes.....	63
<b><i>Connecting Peripheral Devices .....</i></b>	<b><i>67</i></b>
Connecting a Phone Line .....	68
Connecting the Internal Modem to the Telephone Line .....	69
Connecting to the Local Area Network (LAN) .....	72
Connecting a Universal Serial Bus (USB) Device ...	74
Connecting an External Display .....	75
Recording from a Microphone or Audio Equipment	77
Adding Memory.....	80
<b><i>About the Software on Your Computer...87</i></b>	
Movie Shaker .....	91
PictureGear™ .....	94
For Answers to Your Software Questions .....	96
<b><i>Using the System and Application Recovery CDs .....</i></b>	<b><i>99</i></b>
<b><i>Troubleshooting.....</i></b>	<b><i>103</i></b>
Getting Help.....	115
<b><i>Specifications.....</i></b>	<b><i>117</i></b>
<b><i>Index.....</i></b>	<b><i>119</i></b>


# Notes

# Notes

# Welcome

Congratulations on your purchase of the Sony VAIO® notebook. Sony has combined leading-edge technology in audio, video, computing, and communications to provide you with state-of-the-art personal computing.

## Features

 For a complete description of the specifications of your VAIO Notebook, see “Specifications” on page 117.

- ❑ **Exceptional performance** — Your notebook includes a fast Mobile Intel® Pentium® III processor 700MHz featuring Intel® SpeedStep™ technology and a V.90/K56flex compatible modem.\*
- ❑ **Portability** — The high-capacity lithium-ion battery provides hours of use without AC power.
- ❑ **Sony audio and video quality** — High-quality MPEG1 digital video, which supports full-screen display (10.4-inch Active Matrix LCD screen) and enables you to take advantage of today’s advanced multimedia applications, games, and entertainment software.
- ❑ **Microsoft® Windows® Operating System** — Your system includes the Microsoft® Windows® Millennium Edition or the Microsoft® Windows® 2000 Professional operating system.
- ❑ **Communications** — Access popular online services, send e-mail, and browse the Internet.

---


\* Actual upload and download speeds may vary due to line conditions, ISP support, and government regulations.




## Unpacking Your Notebook

**Remove the following hardware items from the box:**


Main unit




Power cord




Rechargeable battery pack



AC adapter



Display Adapter



### Manuals


- ❑ **The VAIO® Notebook User Guide** — Contains information on setting up your notebook, supplementary updates and software information. This manual describes the features and specifications of your notebook, the applications included with your system, how to contact software vendors, and solve common problems.
- ❑ **The Microsoft® Windows® Millennium Edition Getting Started manual or Microsoft® Windows 2000 Professional Getting Started manual** — Explains how to use the basic features of the Windows operating system.

### Software CD

- ❑ **Microsoft® Word 2000 CD** — Allows you to reinstall Microsoft Word to the Sony computer you purchased.

## **Recovery CDs**

- ❑ **System Recovery CD(s)** — Allows you to restore the software titles that were shipped with your computer if they become corrupted or are erased accidentally. It can be used only to restore the hard disk of the Sony computer you purchased.
- ❑ **Application Recovery CD(s)** — Allows you to reinstall individual applications or device drivers if they are corrupted or accidentally erased.

 To use these recovery CDs, you need to purchase either the PCG-CD51/A CD-ROM drive, or the PCGA-DVD51/A DVD drive. (Windows Me does not support PCGA-CDRW51).


## **Other**

- ❑ Setting up your VAIO® Notebook (poster)
- ❑ Packet containing special product offers

## Ergonomic Considerations

You will be using your notebook computer as a portable device in a variety of environments. Whenever possible, you should apply the following ergonomic considerations to both stationary and portable environments.

### Recommended Position



- ❑ **Position of your computer** — Place the computer directly in front of you as you work. Keep your forearms horizontal, with your wrists in a neutral, comfortable position while using the keyboard, touchpad, or external mouse. Let your upper arms hang naturally at your sides. Take breaks during sessions with your computer. Excessive use of the computer may strain muscles or tendons.
- ❑ **Furniture and posture** — Sit in a chair with good back support and armrests. Adjust the level of the chair so your feet are flat on the floor. A footrest may make you more comfortable. Sit in a relaxed, upright posture and avoid slouching forward or leaning far backward.
- ❑ **Viewing angle of the computer's display** — Use the display's tilting feature to find the best position. You can reduce eye strain and muscle

fatigue by adjusting the tilt of the display to the proper position. You can adjust the brightness setting of the display also.

- ❑ **Lighting** — Choose a location where windows and lights do not create glare or reflection on the display. Use indirect lighting to avoid bright spots on the display. You can also purchase accessories for your display that help reduce glare. Proper lighting adds to your comfort and work effectiveness.
- ❑ **Placement of an external display** — When using an external display, set the display at a comfortable viewing distance. Make sure the display screen is at eye level or slightly lower when you are sitting in front of the monitor.

## ***Notes on Setup***

### ***Setting Up Your Notebook***

- ❑ Do not place your computer in a location subject to:
  - ❑ Heat sources, such as radiators or air ducts
  - ❑ Direct sunlight
  - ❑ Excessive dust
  - ❑ Moisture or rain
  - ❑ Mechanical vibration or shock
  - ❑ Strong magnets or speakers that are not magnetically shielded
  - ❑ Ambient temperature of more than 95° F (35° C) or less than 40° F (5° C)
  - ❑ High humidity
- ❑ Do not place electronic equipment near your computer. The computer's electromagnetic field may cause a malfunction.
- ❑ Provide adequate air circulation to prevent internal heat build-up. Do not place your computer on porous surfaces such as rugs or blankets, or near materials such as curtains or draperies that may block its ventilation slots. Leave a space of at least 8 inches behind the back panel of the computer.
- ❑ The computer uses high-frequency radio signals and may cause interference to radio or TV reception. Should this occur, relocate the computer a suitable distance away from the set.
- ❑ Use only specified peripheral equipment and interface cables; otherwise, problems may result.

- ❑ Do not use cut or damaged connection cables.
- ❑ Your computer will not work with party lines, cannot be connected to a coin-operated telephone, and may not work with multiple phone lines or a private branch exchange (PBX).
- ❑ If the telephone company makes a service call to your home or office and determines that your computer is responsible for a problem, the telephone company may bill you for the service call. Also, if you do not disconnect your computer when it is adversely affecting the telephone line, the telephone company has the right to disconnect your service until you correct the problem.

### ***Handling Your Notebook***

- ❑ Clean the cabinet with a soft, dry cloth or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzine, as these may damage the finish of your computer.
- ❑ Should any solid object or liquid fall into the computer, shut down your computer and then unplug it. You may want to have the computer checked by qualified personnel before operating it any further.
- ❑ Do not drop the computer or place heavy objects on top of the computer.

### ***Cleaning Your Notebook***

- ❑ Make sure to disconnect the AC adapter before cleaning the computer.
- ❑ Avoid rubbing the LCD screen as this can damage the screen. Use a soft, dry cloth to wipe the LCD screen.
- ❑ Clean the computer with a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent, such as alcohol or benzine.

### ***Handling the LCD Screen***

- ❑ Do not leave the LCD facing the sun as it can damage the LCD. Be careful when using the computer near a window.
- ❑ Do not scratch the LCD or exert pressure on it. This could cause malfunction.

- ❑ Using the computer in low temperature conditions may produce a residual image on the screen. This is not a malfunction. When the computer returns to normal temperature, the screen returns to normal.
- ❑ A residual image may appear on the screen if the same image is displayed for a lengthy period of time. The residual image disappears in a while. You can use a screen saver to prevent residual images.
- ❑ The screen becomes warm during operation. This is normal and does not indicate a malfunction.
- ❑ The LCD is manufactured using high-precision technology. You may, however, see tiny black points and/or bright points (red, blue, or green) that continuously appear on the LCD. This is a normal result of the manufacturing process and does not indicate a malfunction.

### ***On Moisture Condensation***

- ❑ If the computer is brought directly from a cold location to a warm one, moisture may condense inside your computer. In this case, allow at least an hour before turning on your computer. If any problems occur, unplug your computer, and contact your Sony Service Center.




# Setting Up Your VAIO® Notebook

This section describes how to start using your computer and how to use your computer's internal and external devices.

## Locating Controls and Connectors

### Front




- |   |                            |
|---|----------------------------|
| 1 | Power indicator            |
| 2 | Battery indicator          |
| 3 | MG Memory Stick® indicator |
| 4 | Hard disk drive indicator  |
| 5 | Num Lock indicator         |




- |           |                                     |
|-----------|-------------------------------------|
| <b>6</b>  | <b><i>Caps Lock indicator</i></b>   |
| <b>7</b>  | <b><i>Scroll Lock indicator</i></b> |
| <b>8</b>  | <b><i>Microphone</i></b>            |
| <b>9</b>  | <b><i>LCD screen</i></b>            |
| <b>10</b> | <b><i>Keyboard</i></b>              |
| <b>11</b> | <b><i>Touchpad</i></b>              |
| <b>12</b> | <b><i>Power</i></b>                 |
| <b>13</b> | <b><i>Left/right button</i></b>     |
| <b>14</b> | <b><i>Speakers</i></b>              |

**Back**




- |          |                                 |
|----------|---------------------------------|
| <b>1</b> | <b><i>Battery connector</i></b> |
|----------|---------------------------------|

**Left**



- |          |  |
|----------|--|
| <b>1</b> | <b>DC In connector</b>   |
| <b>2</b> | <b>Air vent</b>  |
| <b>3</b> | <b>VGA adapter output (for connecting an external display)</b> |
| <b>4</b> | <b>USB connector</b>   |
| <b>5</b> | <b>Memory Stick® media slot</b>                                |
| <b>6</b> | <b>Memory Stick eject button</b>                               |


**Right**



- |          |                                     |
|----------|-------------------------------------|
| <b>1</b> | <b>Headphone connector</b>          |
| <b>2</b> | <b>Microphone/Line IN connector</b> |
| <b>3</b> | <b>Jog Dial™ control</b>            |
| <b>4</b> | <b>PC Card eject button</b>         |
| <b>5</b> | <b>PC Card slot</b>                 |
| <b>6</b> | <b>i.LINK®* (IEEE1394) S400</b>     |
| <b>7</b> | <b>Phone line jack</b>              |

\* i.LINK is a trademark of Sony used only to designate that the unit contains an IEEE1394 connector. All products with an i.LINK connector may not communicate with each other.

**Bottom**



- 
- |          |                              |
|----------|------------------------------|
| <b>1</b> | <b>Battery lock lever</b>    |
| <b>2</b> | <b>Battery release lever</b> |
- 


## Connecting a Power Source

You can use either AC power or a rechargeable battery pack as a power source.

### Using the AC Adapter

- 1 Plug the cable attached to the AC adapter (PCGA-AC16V1) into the DC In connector on the notebook.
- 2 Plug one end of the power cord into the AC adapter.
- 3 Plug the other end of the power cord into an AC outlet.

### Connecting AC Adapter



## Using Battery Power


You can use a battery pack as a source of power. The PCGA-BP2S battery pack that comes with your notebook is not fully charged at the time of purchase. Follow the steps below to insert and charge the battery pack.

### To Insert the Battery Pack

You can insert or remove the battery pack without turning off the notebook when your notebook is connected to the AC adapter. Before inserting or removing a battery pack, close the cover.


- 1 Move the lock lever on the bottom of the notebook to the **UNLOCK** position.

#### Lock Lever



- 2 Align the grooves and tabs on the battery with the tabs and notches on the back of the notebook, and then slide the battery toward the notebook until it clicks into place.

#### Inserting Battery Pack



- 3 Slide the lock lever into the **LOCK** position to secure the battery on the notebook.


### To Charge the Battery Pack

- 1 Connect the AC adapter to the notebook.
- 2 Insert the battery pack.

The notebook automatically charges the battery (the battery indicator light flashes in a double-blink pattern as the battery charges). When the battery is 85% full, the battery indicator light turns off. This process takes 2 hours if the system is off, 5.5 hours if the system is on. To charge the battery completely, continue charging for approximately 3.5 additional hours.

The  battery indicator light on the front of the notebook indicates the status of the battery pack.

### Battery Indicator Light



<b>Battery Indicator Light Status</b>	<b>Meaning</b>
<b>On</b>	The notebook is using battery power.
<b>Single blink</b>	The battery is running out of power.
<b>Double blink</b>	The battery is charging.
<b>Off</b>	The notebook is using AC power.


 Both the battery and power indicators blink when the battery is running out of power.

### To Remove the Battery Pack

You can insert or remove the battery pack without turning off the notebook when your notebook is connected to the AC adapter. Before inserting or removing a battery pack, close the cover.

- 1 Turn off the notebook and close the cover.
- 2 Slide the lock lever to the **UNLOCK** position.
- 3 Slide the release lever to the **UNLOCK** position and slide the battery away from the notebook.

### **Removing Battery Pack**



You may lose data if you remove the battery pack while the notebook is on and not connected to the AC adapter or if you remove the battery while the notebook is in a power saving mode.

### **Notes on Power**

#### **The AC Adapter**

- ☐ Your computer operates on 100-240V AC 50/60Hz.
- ☐ Do not share the AC outlet with other power-consuming equipment, such as a copying machine or shredder.
- ☐ You can purchase a power strip with a surge protector. This device prevents damage to your computer caused by sudden power surges such as those that may occur during an electrical storm.
- ☐ Do not place heavy objects on the AC adapter or its cord.
- ☐ To disconnect the cord, pull it out by the plug. Never pull the cord itself.
- ☐ Unplug your computer from the wall outlet if you will not be using the computer for a long time.
- ☐ When the AC adapter is not used, unplug it from the AC outlet.
- ☐ Use only the AC adapter supplied. Do not use any other AC adapter.

### **Hardware Temperature**

- ❑ The AC adapter or the bottom panel of your notebook may become warm. This is the result of CPU operation and does not indicate a malfunction of the notebook. The actual temperature varies depending on the peripherals and software you are using and the length of time that the unit is in use.
- ❑ The AC adapter may also become warm when the notebook is off and the battery is charging.



**Do not cover the notebook or adapter with clothing, blankets, or any other material when the notebook is turned on. Covering these components may result in damage to your unit.**

**When connecting the supplied AC adapter to an AC outlet that has more than two outlets, do not plug the AC adapter into an outlet that is obstructed by another adapter. To prevent fire or electrical shock, the adapter must be firmly plugged into the outlet. If necessary, use a separate AC outlet.**

### **Using Batteries**

- ❑ Never leave the battery pack in temperatures above 140° F (60° C), such as under direct sunlight or in a car parked in the sun.
- ❑ Battery life is shorter in a cold environment. This is due to decreased battery efficiency at low temperatures.
- ❑ Charge the batteries at temperatures between 50° F and 80° F (10° C to 30° C). Lower temperatures require a longer charging time.
- ❑ While the battery is in use or being discharged, the battery pack heats up. This is normal and is not cause for concern.
- ❑ Keep the battery pack away from all sources of heat.
- ❑ Keep the battery pack dry.
- ❑ Do not open or try to disassemble the battery pack.
- ❑ Do not expose the battery pack to any mechanical shock.
- ❑ If you are not using the computer for an extended period of time, remove the battery pack from the computer to prevent damage to the battery.
- ❑ If, after fully charging the battery pack, the battery power is still low, the battery pack may be reaching the end of its life and should be replaced.
- ❑ You do not need to discharge the battery before recharging.




- ❑ If you have not used the battery pack for a considerable amount of time, recharge the battery.
- ❑ Keep the battery pack in the notebook while it is directly connected to AC power. The battery pack continues to charge while you are using the notebook.
- ❑ If your battery level falls to less than 10%, you should either attach the AC adapter to recharge the battery or shut down your notebook and insert a fully-charged battery.
- ❑ You can extend battery life by changing the power management modes in the Power Panel utility. See “Using Power Saving Modes” on page 63
- ❑ The battery pack supplied with your notebook is a lithium ion battery and can be recharged at any time. Charging a partially discharged battery does not affect battery life.
- ❑ The battery indicator light is on while you use the battery pack as a power source. When battery life is nearly depleted, the battery indicator starts flashing.
- ❑ Your notebook may not enter System Hibernation mode when the battery life is low, when certain software applications are running, or when certain peripheral devices are connected. To avoid loss of data when using battery power, you should save your data frequently and manually activate a power management modes, such as System Suspend or System Hibernation.

## Starting Your Computer


- 1 Slide the LCD lock lever in the direction of the arrow, and lift the cover.

### Opening



- 2 Slide the power switch to the right until the green power indicator turns on.

### Power Switch



**(Windows Me only)** When starting your notebook for the first time, the VAIO InitManager dialog box will appear. Please select “OK” to begin initial setup. If you do not execute the initial setup, you cannot use part of VAIO original hardware functions such as Jog Dial Control, Power Management tool, scroll function of touchpad, and keyboard shortcut key function combined with the Fn key.

- 3 If necessary, adjust the brightness controls for the LCD display. To decrease the brightness, press Fn+F5 and then the down or left arrow key. To increase the brightness, press Fn+F5 and then the up or right arrow key.

## Shutting Down Your Computer



**To avoid potential loss of data, follow these steps to shut down your computer.**

- 1 Click the Start button on the Windows® taskbar.
- 2 Click Shut Down at the bottom of the Start menu to display the Shut Down Windows dialog box.
- 3 From the drop-down list, select Shut Down.
- 4 Click OK.



Respond to any prompts warning you to save documents.

- 5 Wait for your computer to turn off automatically. The power indicator turns off.
- 6 Turn off any peripheral devices connected to your computer.



During a period of inactivity, you can conserve battery life by using System Suspend mode. See “Controlling Power Management” in the online manual *Customizing Your Notebook*. To access the online documents, click the Start button, point to Help Center, and click VAIO User Manuals.

### ***If you are unable to shut down your computer:***

- 1 Close or end all operations:
  - ☐ close all applications
  - ☐ remove the PC cards
  - ☐ disconnect USB devices
  - ☐ end Infrared Communication
- 2 Restart the computer. You can restart your computer by pressing the Ctrl+Alt+Delete keys (at the same time).




If you are still unable to shut down the computer, you can press the power button and hold it for four seconds. This operation may result in data loss.

# Using Your VAIO® Notebook



## Using the Keyboard

Your keyboard is very similar to a typewriter's, but the keyboard has additional keys that perform specific computer-related tasks.










### Keyboard










Key	Description
<b>Numeric keypad area</b>	Contains the keys found on a typical calculator. Use the numeric keypad area to type numbers or to perform mathematical calculations such as addition and subtraction. Note that you must press the Num Lock key to activate the numeric keypad. (When you do so, the Num Lock light will be on.)
<b>Navigation keys</b>	Several keys are devoted to moving the cursor on the screen (the four arrow keys which also function as the Home, End, Page Up, and Page Down keys).
<b>Correction keys</b>	The Insert, Back Space, and Delete keys enable you to make corrections in your documents.

<b>Key</b>	<b>Description</b>
<b>Function keys</b>	The 12 function keys along the top of the keyboard are used to perform designated tasks. For example, in many applications, F1 is the Help key. The task associated with each function key may vary from one application to the next.
<b>Escape key</b>	The Esc (Escape) key is used to cancel commands.
<b>Print Screen key</b>	The Print Screen key takes an electronic snapshot of the screen and places it in the Windows Clipboard. You can then paste the screen shot into a document and print it.
<b>Operator keys</b>	Several keys are always used with at least one other key: Ctrl, Alt, and Shift. When held down with another key, the Ctrl (Control) and Alt (Alternate) keys offer another way to give commands. For example, in many applications, instead of choosing the Save command from a menu, you can hold down Ctrl and press S (referred to as Ctrl+S). The Shift key operates the same way as on a typewriter; it is used to produce capital letters or special symbols such as @ and \$.
<b>Windows key</b> 	The key with the Windows logo displays the Windows Start menu; it is the equivalent of clicking the Start button on the task bar. See “Combinations and Functions with the Windows Key” on page 35.
<b>Fn key</b>	The Fn key is used in combination with other keys to issue commands. The Fn keys at the left and right sides both work the same. See “Combinations and Functions with the Fn Key” on page 37.
<b>Applications key</b> 	The Applications key displays a shortcut menu of context-sensitive choices; pressing this key is the equivalent of clicking the right mouse button.


















## ***Combinations and Functions with the Windows Key***

<b><i>Combinations</i></b>	<b><i>Functions</i></b>
 + <b>F1</b>	Displays Windows Help.
 + <b>Tab</b>	Switches the selected button on the taskbar.
 + <b>E</b>	Displays Windows Explorer.
 + <b>F</b>	Displays the Windows Find: All Files window to find a file or folder. This is the equivalent of selecting Find and then Files or Folders from the Start menu.
 + <b>Ctrl + F</b>	Displays the Windows Find: Computer window where you can locate other computers. This is the equivalent of selecting Find and then Computer from the Start menu.
 + <b>M</b>	Minimizes all displayed windows.
<b>Shift</b> +  + <b>M</b>	Returns all minimized windows to their previous size.
 + <b>R</b>	Displays the Run window. This is the equivalent of selecting Run from the Start menu.
<b>Fn</b> +  + <b>Insert</b>	Displays the Properties window. This is the equivalent of clicking the System icon in the Control Panel.

## Indicators

<b>Indicators</b>	<b>Functions</b>	
<b>Power</b> 	Lights when the power to the computer is turned on. Flashes in System Suspend mode. Turns off when the computer is in System Hibernation mode or powered off.	
<b>Battery</b> 	Indicates the status of the battery attached at the rear of the computer.	
<b>MG Memory Stick</b> 	Indicates the <b>Memory Stick</b> slot is in use.	
<b>Light</b>	<b>On</b>	<b>Off</b>
<b>Hard disk</b> 	Data is being read from or written to the hard drive. Do not enter System Suspend mode or turn off the computer when this indicator light is on.	The hard drive is not being accessed.
<b>Num Lock</b> 	The number keys in the numeric keypad are active.	The character keys in the keypad area are active.
<b>Caps Lock</b> 	The letters appear in uppercase as you type. The Shift key lowers the case of typed letters when Caps Lock is on.	Letters appear in lower case as you type (unless you hold down the Shift key).
<b>Scroll Lock</b> 	The screen scrolls differently. (Exactly how it scrolls depends on the specific application. It has no effect in many applications.)	Information moves across the display normally.

## Combinations and Functions with the Fn Key

<b>Combinations/ Feature</b>	<b>Functions</b>
<b>Fn+  (F3) System Suspend</b>	Puts the system into System Suspend mode, a power management state. To return the system to the active state, press any key or press the power switch on your computer.
<b>Fn+  (F3) Mute on/off</b>	Toggles the built-in speaker off and on.
<b>Fn+  (F4) Speaker volume</b>	Adjusts the built-in speaker volume. To increase volume, press Fn+F4, then  or  . To decrease volume, press Fn+F4, then  or  .
<b>Fn+  (F5) Brightness control</b>	Adjusts the brightness of the LCD. To increase light intensity, press Fn+F5 and then  or  . To decrease light intensity, press Fn+F5 and then  or  .
<b>Fn+  /  (F7) Switch to the external display</b>	Toggles through the LCD, external display (connected to the  Monitor connector on the port replicator) and both LCD and external display. <div style="text-align: center;">  </div>
<b>Fn+  (F12) System Hibernation</b>	Provides for the lowest level of power consumption. When you execute this command, the state of the system and state of the peripheral devices are written to the hard disk and the system power is turned off. To return the system to the original state, use the power switch to turn on power.
<b>Fn+B Mega-Bass switch</b>	Toggles the mega-bass function off and on. This feature is available with headphone only.
<b>Fn+S System Idle</b>	Puts the system into System Idle mode, a power management state. To return the system to the active state, press any key.



You can also carry out these functions using the Jog Dial control.


Some functions are not available until Windows launches.



# Using the Touchpad

The keyboard contains a cursor-pointing device called a touchpad. You can point to, select, drag, and scroll objects on the screen using the built-in touchpad.

## Touchpad



<b><i>Actions</i></b>	<b><i>Descriptions</i></b>
<b><i>Point</i></b>	Slide one finger on the touchpad to place the pointer on an item or object.
<b><i>Click</i></b>	Press the left button once.
<b><i>Double-click</i></b>	Press the left button twice.

<b><i>Actions</i></b>	<b><i>Descriptions</i></b>
<b><i>Right-click</i></b>	Press the right button once. In many applications, this action displays a shortcut menu of context-sensitive choices.
<b><i>Drag</i></b>	Slide one finger while pressing the left button.
<b><i>Scroll</i></b>	Move your finger along the right edge of the touchpad to scroll vertically. Move your finger along the bottom edge to scroll horizontally. (The scroll function is available only with applications that support a touchpad scroll feature.)




See Mouse Properties for information on touchpad features, such as clicking both buttons simultaneously, adjusting touchpad speed, Web Assist, Tap Off, and Easy Launcher functions. To access Mouse Properties, click the Start button on the Windows taskbar, point to settings, and then select Control Panel. Click the Mouse icon to open Mouse Properties.

## Using a Floppy Disk Drive (optional)


You can connect a Sony floppy disk drive (PCGA-UFD5) to the  $\Psi$  (USB) connector on your computer:

### To Connect a Floppy Disk Drive

 You do not need to shut down the computer before connecting or disconnecting a floppy disk drive.

Plug the USB cable from the optional floppy disk drive into the  $\Psi$  (USB) connector on the computer. The VAIO logo on the disk drive should be facing up.


### Connecting a Floppy Disk Drive



### ***To Insert a Diskette***

- 1 Hold the diskette with the label side facing up.
- 2 Gently push the diskette into the drive until it clicks into place.


### ***Inserting a Diskette***




### ***To Remove a Diskette***


- ☐ When you finish using the diskette, wait until the LED indicator turns off and then press the Eject button to remove the diskette.

### ***Removing a Diskette***



### ***Removing a Floppy Disk Drive When the Computer is On***

 If your computer is turned off, you do not have to follow these instructions.

- 1 Double-click  in the task tray.
- 2 The “Unplug or Eject Hardware” dialog displays.
- 3 Select the hardware device you wish to remove by clicking it.
- 4 Click Stop.

- 5 Confirm the correct device is selected in the “Stop a hardware device” dialog box.
- 6 The message “Floppy Disk Drive can now be safely removed from the system” appears. Click OK.
- 7 Slide the release lever on the bottom of the computer in the direction of the arrow, and then unplug the floppy disk drive from the computer.



**(Windows Me only) If you remove the USB Disk, the internal memory stick becomes disabled.**

**If you have removed the USB Disk by mistake (instead of the USB floppy), take the following steps to recover it.**

**Open the start menu, select Settings, Control Panel, and then the System icon. The Device Manager appears.**

**Click the Refresh button.**

**In the “Stop a Hardware device” dialog box, confirm that the device can be safely removed from the system. Click OK.**

### ***To Carry a Floppy Disk Drive***

Fold the floppy disk cable into the compartment on the side of a floppy disk drive.

### ***Carrying a Floppy Disk Drive***




### ***Notes on the Floppy Disk Drive***


#### ***Handling Diskettes***

- ☐ Do not open the shutter manually and touch the surface of the diskette.
- ☐ Keep diskettes away from magnets.
- ☐ Keep diskettes away from direct sunlight and other heat sources.

## **Connecting the CD/DVD Drive (optional)**

You can purchase the optional CD-ROM drive (PCGA-CD51/A), or DVD drive (PCGA-DVD51/A), to use with your notebook. If you use any optical drive when your notebook is running on battery power, the battery life will be shorter. The drive draws power from the notebook through a PC card. DVD-ROM drives play both DVDs and CDs.


 Windows Me does not support PCGA-CDRW51.

 Procedures for connecting the CD drive may vary, depending on the CD drive. See the manual that came with your CD drive for more information on use.

***(Windows 2000 only) To play an audio CD in the optional CD-ROM drive, your notebook's settings must be set properly. You can check the settings as follows***


- 1 Click the Start button, point to Settings, and then click Control Panel.
- 2 Double-click the System icon.
- 3 Click the Hardware tab and then click Device Manager.
- 4 Double-click the drive you use under DVD/CD-ROM drive.
- 5 Click the Property tab and make sure the "Enable digital CD audio for this CD-ROM device" box is checked.

### ***To Connect the CD Drive***

 You can connect a CD-ROM drive (PCGA-CD51/A) or DVD drive while the notebook is on, unless you plan to use the System and Application Recovery CDs. Turn off your notebook before using the System and Application Recovery CDs.


- 1 Remove the PC card slot protector from the PC card slot. See "Using PC Cards" on page 47 for details.
- 2 Remove the PC card from the bottom side of the CD drive.


### **Removing the PC Card**



- 3 Insert the PC card into the PC card slot with the SONY logo facing up. See “Using PC Cards” on page 47 for details.

### **Inserting the PC Card**




 A protective cover is attached to the lens of the CD-ROM drive at the factory. Before using the CD-ROM drive, remove this protective cover.

### ***To Insert a Disc***


- 1 Press the Eject button. The disc tray slides out.

### ***Using the CD-ROM Drive***



- 2 Place the disc in the tray with the label side facing up. Push the disc onto the hub until the disc clicks into place.


### ***Inserting a Disc***



- 3 Close the tray by pushing it gently. The BUSY indicator on the drive flashes while your notebook is reading data from the disc.



### ***The Flashing BUSY Indicator***



### ***To Remove the Drive***

Remove the PC card from the notebook. See “Using PC Cards” on page 47 for details.


### ***Notes on CD and DVD Media***

#### ***Handling CD or DVD Media***

- ☐ Do not touch the surface of the disc.
- ☐ Do not drop or bend the disc.
- ☐ Do not use adhesive labels to identify the disc. The label may come off while the disc is in use in the optical drive and cause the drive to malfunction.
- ☐ Fingerprints and dust on the surface of a disc may cause read errors. Proper care of the disc is essential to maintain its reliability. Do not use solvents such as benzine, thinner, commercially available cleaners or anti-static spray, as they may cause damage to the disc.
- ☐ For normal cleaning, hold the disc by its edge and use a soft cloth to wipe the surface from the center out.
- ☐ If the disc is badly soiled, moisten a soft cloth with water, wring it out well, and use it to wipe the surface of the disc from the center out. Wipe off any remaining moisture with a dry soft cloth.

## Using PC Cards

Your notebook includes a PC card slot. PC cards allow you to connect portable external devices, such as a CD-ROM drive.

 The PC card slot can accommodate one Type I or Type II PC card. This slot is compatible with 16 bit card and Card Bus. ZV (Zoomed Video) port is not available.

Some PC cards may require that you disable idle devices when using the PC card. You can use Sony Notebook Setup to disable devices. See “Displaying the Sony Notebook Setup Screen” in the online manual *Customizing Your VAIO® Notebook* for details.

Be sure to use the most recent software driver provided by the PC card manufacturer.


If an “!” mark appears on the Device Manager tab in the System Properties dialog box, remove the software driver and then reinstall it.

### To Insert a PC Card

 You do not need to shut down the notebook before inserting or removing a PC card.

- 1 Extend the PC card release button out and away from the notebook and then push it in towards the notebook.


### Removing the PC Card Slot Protector



- 2 Remove the PC card slot protector.

- 3 Insert the PC card into the PC card slot, front label facing up. Gently push the card into the slot until the card is fixed into the connector. The release button extends.

### ***Inserting a PC Card***



Do not force a PC card into the slot, as this may damage the connector pins.


If you have difficulty inserting a card, check that you are inserting the card with the correct orientation.


Do not carry your computer while touching the head of a PC card (such as a wireless LAN card), pressure or shock may damage the connector pins.

For some PC cards, if you alternate between normal power operation and the System Suspend or System Hibernation power management modes while the card is inserted, you may find that a device connected to your system is not recognized. Reboot your system to correct the problem.


See the manual that came with your PC card for more information on its use.

### ***To Remove a PC Card When the Computer is on.***

 If your computer is turned off, you do not have to follow these instructions.

- 1 Double-click  in the task tray.
- 2 The “Unplug or Eject Hardware” dialog displays.
- 3 Select the hardware device you wish to remove by clicking it.
- 4 Click Stop.
- 5 Confirm the correct device is selected in the “Stop a hardware device” dialog box.
- 6 The message, “PC Card can now be safely removed from the system” appears. Click OK.

### ***Removing a PC Card***




- 7 Gently grasp the card and pull it out.
- 8 Insert the PC card slot protector into the empty slot.

## Using Smart Connect

### Windows Me

You can connect your VAIO® notebook to another VAIO computer that has the preinstalled Windows Me operating system or the Sony Smart Connect 3.0 software preinstalled. You may use an i.LINK® cable (optional) to connect the two systems and then use one computer to edit, copy, or delete files on the other computer. You can also print from a printer that is attached to either computer. Select the STD mode in Smart Connect 3.0 software to connect with another computer that has Windows Me preinstalled.


#### Connecting with an i.Link Cable



### Windows 2000


The preinstalled Smart Connect software allows you to use an i.LINK® cable (optional) to connect your VAIO notebook to another VAIO computer that also has Smart Connect or preinstalled Windows Me. You can then use one computer to edit, copy or delete files on the other computer. You can also print from a printer attached to either computer.

See Smart Connect online help for more information.

 When you connect two VAIO computers, you must assign each computer a unique name. The computers can be identified by this unique name when the two computers are networked together.

 If you have previously purchased a VAIO computer or notebook that does not have the Windows Me operating system or Smart Connect 3.0 software preinstalled, consult the Sony website for support options (<http://www.sony.com/pcsupport>).


## i.LINK® Interface

Your notebook comes equipped with an i.LINK S400  port. The port is a digital interface (IEEE1394) for high-speed communication. By using your notebook, a Sony Digital Handycam® Camcorder or other compatible camera that supports the i.LINK interface, the DVgate™ software preinstalled on your computer, and the i.LINK interface, you can easily create and edit your own home videos. For more information on connecting an i.LINK device, see “Connecting an i.LINK® device” on page 51.


## Connecting an i.LINK® device


Your VAIO® notebook includes an i.LINK (IEEE1394) connector, which you can use to connect to an i.LINK device such as a compatible digital video camera recorder.

### To connect a Digital Video Camera Recorder

Plug one end of an i.LINK cable into the  S400 connector on the right side of the computer and the other end into the DV In/Out connector on the digital video camera recorder. If your digital video camera recorder includes a **Memory Stick** slot, you can copy images from it to your computer via a **Memory Stick** media. Copy images to the **Memory Stick** media and insert the media into the **Memory Stick** slot on your computer. For details on using **Memory Stick**, see “Using Memory Stick® Media” on page 57.

### Connecting a Digital Video Camera Recorder



 The Sony digital video camera recorder is pictured; your digital video camera recorder may need to be connected differently.

Only Sony digital video cameras, and connectors labeled “DV In/Out” or “i.LINK” are i.LINK-compatible.

See the manual that came with your digital video camera recorder for more information on installation and use.

The i.LINK connector does not supply power to external devices. If the external device requires power from the i.LINK connector, you cannot use the device with your computer.

The VAIO® notebook supports transfer rates up to 400 Mbps; however, the actual transfer rate is the lowest transfer rate of the external device.

The i.LINK features available may vary depending on the software applications you use. See the documentation that came with your software for more information.

i.LINK cables compatible with your VAIO notebook: VMC-IL4415 (a 1.5-meter cable with a 4-pin connector at each end), VMC-IL4615 (a 1.5-meter cable with a 4-pin connector at one end and a 6-pin connector at the other), and VMC-IL4408A (a 0.8-meter cable with a 4-pin connector at each end).

You can purchase these cables from your local retailer, through the Sony VAIO® Direct Web site (<http://vaio.sonymstyle.com/>), or by calling 1-888-315-7669 (toll free).

## ***DVgate™ Applications***

### ***Digital Video Captures***

If your system displays the message “Failed to record to DV deck. Please check deck’s power status, cable connection and so on.” while you are recording images to a digital video device using DVgate, close all open applications, and restart your computer. Frequent recording of images to a digital video device while using DVgate may cause this to occur occasionally.

For more information on DVgate, see the DVgate online help.

### ***Adjusting Image Resolution***

If the images on the LCD do not display smoothly, this may be because the incorrect resolution is selected. To check the resolution, click the Setup button in the DVgate Motion-Monitor window. Point to Settings, then select Low Resolution. The settings you change in this menu affect only the images in the monitor window. Movie data imported to the hard disk and images recorded to DV devices will not be affected.



### ***Hard Drive Partition***

In order to improve the performance of your computer's DVgate™ Motion software, the hard disk drive on your computer has been formatted with two partitions, C and D.\* DVgate Motion saves files to the D partition. This prevents large video captures from consuming the available space on your C partition. To maintain optimum performance of DVgate Motion, you should defragment your D partition regularly. See the DVgate Motion online help for more information.

\*See "Specifications".



## VAIO Action Setup

VAIO Action Setup manages the settings for your computer's Jog Dial™ control, **Memory Stick® media**, and i.LINK® interface. An overview of some of the functions controlled by VAIO Action Setup is provided. For more information on changing the settings using VAIO Action Setup, right-click the Jog Dial control icon  or , in the task tray and click Help Topics.


## The Jog Dial™ Control

This section explains how to use the Jog Dial control. For information on how to change the Jog Dial control settings, right-click the Jog Dial control icon in the task tray and click Help Topics.

### Using the Jog Dial™ Control

Your computer is equipped with a Jog Dial control on the right side of the unit. The Jog Dial control enables you to open an application, folder, or document from a predefined list by rotating and pressing the Jog Dial control. In addition, when you press the Jog Dial control, you can turn on your computer automatically and start the selected application or document.

#### Jog Dial Control



The Jog Dial control window always appears in the display. It is either in the launcher mode or in the guide mode.

### ***Launcher Mode***

The Jog Dial control window is in launcher mode until a software application is launched or the Jog Dial control window becomes active. When an arrow is displayed next to an item in the Jog Dial control window, you can display a submenu of that item by selecting it and pressing the Jog Dial control button.

### ***Using Launcher Mode***

To use the Jog Dial control, click the Jog Dial control window or the Jog Dial control icon in the task tray. Alternatively, you can press the Jog Dial control while pressing the Ctrl key on the keyboard to switch to the launcher mode.

- 1 Turn the Jog Dial control to select the item you want, then press the Jog Dial control. The window switches to the guide mode, and shows the Jog Dial's function.

### ***Jog Guide Dialog Box***



- 2 Turn or press the Jog Dial control to use the desired function.
- 3 To select another item, switch to the launcher mode and repeat from step 1.

### ***Guide Mode***

The Jog Dial control window is in the guide mode when software is in use and the software window is active. Depending on the software you are using, you can select items from the displayed list using the Jog Dial control. Some Sony software applications have two modes in List View, Simple Menu and Full Menu. You can switch the mode by pressing the shift key while turning the Jog Dial control.

## ***Using Guide Mode***

The Jog Dial control window displays the Jog Dial's function.

## ***Using the Jog Dial Control with Sony Software***

If Sony software that supports the Jog Dial control is active, you can use the Jog Dial's functions that are allocated to that software. For more information on functions allocated to software, see the software applications online Help.

## ***Using the Jog Dial Control with Other Software***

If the software you are using does not support the Jog Dial control, you can still perform the following functions:

<b><i>Action</i></b>	<b><i>Description</i></b>
<b><i>Maximize or Minimize Window*</i></b>	Press the Jog Dial control button to maximize the size of the active window. Press again to minimize or return to normal window size.
<b><i>Finish Window*</i></b>	Press the Jog Dial control button to close the active application.
<b><i>Scroll</i></b>	Press the Jog Dial control button to begin scrolling within the active window.
<b><i>Jog Dial Launcher</i></b>	Press the Jog Dial control button to return the Jog Dial control to Jog Launcher mode.
<b><i>Menu Bar</i></b>	Press the Jog Dial control button, then use the Jog Dial control to scroll through the active window's toolbar.

---

\*Some software does not support these functions.

### Using a Dialog Box

When a window such as Screen Properties is active, the Dialog box is displayed in the Jog Dial window. You can select an item in the window by rotating the Jog Dial control. Pressing the Jog Dial control is the equivalent of pressing Enter.



#### Jog Guide Dialog Box



## Using Memory Stick® Media

This new compact, portable, and versatile recording medium has a data capacity exceeding that of a floppy disk. The media is specially designed for exchanging and sharing digital data with compatible products. Because it is removable, the media can be used for external data storage.

### Types of Memory Stick Media

Two types of **Memory Stick** media are available. The first type, **MagicGate™**  (hereafter referred to as **MG Memory Stick** media), is provided with copyright protection. The second type, simply referred to as **Memory Stick**  media, does not have the same copyright protection as MagicGate media.

You can use both media with your notebook.

For music, which requires copyright protection, you can only use **MG Memory Stick** media with your notebook. You can also use MagicGate-compatible devices to record and playback music when they are connected to your computer.

You can store mixed data on the **Memory Stick** media. For example, you can copy an image on to **MG Memory Stick** media that already contains music.

### ***What is MagicGate?***

MagicGate is copyright protection that consists of authentication and encryption technology. Authentication technology ensures that protected content is only transferred between compliant devices and media. Protected content is recorded and transferred in an encrypted format to prevent unauthorized duplication or playback.

 Ensure that the **MG Memory Stick** media has the MG mark .

### ***Handling and Storing Memory Stick Media***


Follow these guidelines when handling and storing **Memory Stick** media.

- ☐ Do not touch the contacts on a **Memory Stick** media with your fingers or any metal object.
- ☐ Use only the labels provided with a **Memory Stick** media. Do not attach other labels to it.
- ☐ Handle the media carefully. Avoid dropping, bending, or subjecting it to shock or vibration.
- ☐ Do not attempt to disassemble the **Memory Stick** media.
- ☐ Do not allow the media to get wet.
- ☐ Avoid using or storing the **Memory Stick** media in any of the following:
  - ☐ Locations subject to high temperatures or direct sunlight (i.e. the interior of a vehicle parked in bright sunlight).
  - ☐ Locations exposed to high humidity or corrosive substances.
  - ☐ Locations that are subject to static electricity or electrical noise generated by large appliances or office equipment.
- ☐ When transporting or storing a **Memory Stick** media, always use its storage case.
- ☐ Always backup important data that is stored on a **Memory Stick** media.
- ☐ Do not remove the media when the indicator light is on.
- ☐ Only **MG™ Memory Stick** media can be used with copyright protected data like music.

## ***Inserting a Memory Stick Media***

Insert the **Memory Stick** media into the media slot on the left side of the computer until it clicks into place. When the **Memory Stick** media is properly in place, Sony VisualFlow™ will automatically launch to display the contents of the **Memory Stick**.

### ***Inserting a Memory Stick Media***



**Hold the Memory Stick media with the arrow pointing toward the slot. To avoid damaging the computer or the Memory Stick media, do not force the media into the slot.**

To confirm that the **Memory Stick** media is inserted correctly, check the Removable Disk (S:) drive.

### ***To check the drive:***

- 1 Double-click the My Computer icon on the desktop.
- 2 Check that the Removable Disk (S:) icon is displayed in the My Computer window.

- 3 Double-click the Removable Disk (S:) icon to display the contents of the Memory Stick media.



If you cannot find the Removable Disk (S:) icon, take the following steps.

Double-click the System icon in Control Panel. Device Manager appears. If you cannot find the icon that you are looking for, click “Display all the options of the Control Panel.”


Click the Refresh button.

### ***Removing a Memory Stick Media***

- 1 Ensure that the Memory Stick media indicator light is off.
- 2 Push in the Memory Stick media eject button.

- 3 When the button ejects, push it again and remove the **Memory Stick** media.

### **Removing a Memory Stick Media**



**Large image files require more time to load to a Memory Stick media.**


### **Using MG Memory Stick Media with Data from Another Device**

**Memory Stick** media can be used with compatible devices like a Sony digital video camera recorder or digital still camera. Insert the media into the Memory Stick media slot and save your movie or still image as data files to the **Memory Stick** media. Use Sony's PictureGear™ software (preinstalled with your notebook) to move the files to a **Memory Stick** media.



For more details on using compatible devices with MG Memory Stick media, refer to the instructions that came with your compatible device, or use PictureGear Help.

### ***Using a Compatible Device***



### ***Write-Protecting a Memory Stick Media***


**Memory Stick** media is designed with a write-protect tab to protect valuable data from accidental erasure or overwriting. Move the tab to the right or left to set or release write-protection.

---

Write-protect off	Data can be saved on the Memory Stick media.
Write-protect on	Data can be read from but not saved on the Memory Stick media.

---

### ***Using the Write-protect Tab***



(Back of Memory Stick media)

## Formatting a Memory Stick Media

**Memory Stick** media is formatted for immediate use when you purchase it. If you need to reformat a **Memory Stick** media, use the **Memory Stick** Formatter that is provided with the media. Follow the procedures included here. For more details about using **Memory Stick** Formatter, refer to Formatter Help.



**Reformatting erases all current data that is stored on a Memory Stick media. Before you reformat, confirm that the media does not contain files you want to keep.**

- 1 Insert the Memory Stick media into the computer. See “Inserting a Memory Stick Media” on page 59 for details on inserting **Memory Stick** media.
- 2 Click the Start button, point to Programs, click **Memory Stick** Utility, and then click **Memory Stick** Formatter.
- 3 Click Start Formatter. **Memory Stick** Formatter begins.

## Using Power Saving Modes

When you use a battery as the source of power for your computer, you can take advantage of power management settings to conserve battery life. In addition to the normal operating mode, which allows you to turn off specific devices, your computer has three distinct power saving modes: System Idle, System Suspend, and System Hibernation. When using battery power, you should be aware that the computer automatically enters System Hibernation mode when the remaining battery charge drops to approximately 10%, regardless of the power management setting you select.



If your battery level falls to less than 10%, you should either attach the AC adapter to recharge the battery or shut down your computer and insert a fully charged battery.

## **Normal Mode**

This is the normal state of your computer when it is in use. The green power indicator light is on in this mode. To save power, you can turn off a specific device such as the LCD or the hard disk.

 For details, see “Controlling Power Management” in the online manual *Customizing Your VAIO® Notebook*.

## **System Idle Mode**

This mode is convenient if you do not need to use your computer for a brief period. The hard disk and video display enter a low power state, and the CPU clock and processor stop. The power indicator light is amber in this mode.

- ☐ To activate System Idle mode:

Press Fn+S. You can also use PowerPanel utility to enter System Idle mode.

- ☐ To return to normal mode:

Press any key.

## **System Suspend Mode**

The computer saves the current state of the system in RAM and switches off power to the CPU. The power indicator light flashes in amber while in this mode.

### **To activate System Suspend mode**

Press Fn+Esc. You can also use the PowerPanel utility to enter System Suspend mode.

### **To return to normal mode**


Press any key.


## **System Hibernation Mode**

The state of the system is saved on the hard drive and power is turned off. The power indicator light is off in this mode.

### ***To activate System Hibernation mode***


To activate System Hibernation mode, press the key combination Fn+F12.

 (Windows 2000 Professional) the “Save to Disk Manager” message appears, and then the computer enters System Hibernation mode.

 Do not move the notebook until its power indicator light turns off.

### ***To return to normal mode***

Turn on the computer by sliding the power switch forward. The computer returns to its previous state.

 When returning from System Hibernation mode, the system status stored on the hard disk is erased and the computer starts normally if you slide the power switch forward and hold for more than four seconds.

- ☐ Time to return to normal mode:  
System Idle requires less time than System Suspend, and System Suspend requires less time than System Hibernation.
- ☐ Power consumption:  
System Idle uses more power than System Suspend, and System Suspend uses more power than System Hibernation.

## ***Notes on Power Management***

### ***Using Power Management***

- ☐ If you find that an application exhibits unexpected behavior (such as reduced video quality) after returning from a power saving mode, you should close that application before your computer enters a power saving mode.
- ☐ For maximum audio and video performance, use PowerPanel to select either the AC Power Profile or the Power Management Off profile.
- ☐ If your battery level falls to less than 10 percent, you should either attach the AC adapter to recharge the battery or shut down your computer and insert a fully charged battery.

- ❑ When the internal backup battery is low on power, it may not be able to boot your system properly. You can correct this situation as follows:
  - ❑ Plug in the AC adapter and allow the computer to charge for one hour while the power is on. Do not use the computer during this time.
  - ❑ After one hour, turn the power off and then on again. To charge the internal backup battery fully, keep the AC adapter connected for more than 24 hours after turning the power on. You can use your computer while charging the battery.
- ❑ The operating system may become unstable if a lower power state such as system hibernation is initiated and then changed before the operating system completely enters the lower power state. To restore the notebook to its normal operating stability, close all open applications, and slide the power switch forward and hold it there for four seconds or more to completely shut down the notebook.


# *Connecting Peripheral Devices*

You can add functionality to your computer by connecting any of these peripherals:

- ☐ Phone line (page 68)
- ☐ Local Area Network (LAN) (page 72)
- ☐ Universal Serial Bus (USB) device (page 74)
- ☐ External display (page 75)


## Connecting a Phone Line

You need to connect a phone line to take advantage of online services, the Internet, and Sony Customer Support.

 In order to register your notebook online, register your software, or use Sony Customer Support, you must connect to a phone line. You must also register your notebook to receive the extended warranty.


- 1 Open the phone line jack cover.


### Opening the Phone Line Jack Cover



- 2 Plug one end of the phone cable (optional) into the jack on the inside of the phone line jack cover. Make sure you insert the phone cable from the rear of the notebook and that the modular jack clicks into place.
- 3 Plug the other end into the wall jack.

### **Plugging the Phone Line into Phone Line Jack**




 Your notebook does not work with party lines, cannot be connected to a coin-operated telephone, and may not work with multiple phone lines. Some of these connections might result in excess electrical current and could cause a malfunction in the internal modem.

## **Connecting the Internal Modem to the Telephone Line**

The notebook comes with an internal fax modem that allows you to exchange data by faxing through the Internet or faxing by connecting the notebook to the telephone line using a phone cable (optional).

The maximum communication speed of the internal modem (V.90, 56K) is 56 Kbps for data reception and 33.6 Kbps for data transmission. This speed may vary depending on the line conditions.

 **Note:** The internal fax modem can only be connected to a subscriber telephone line. Do not connect it to a PBX (Private Branch Exchange). Connecting to the PBX may cause a major system malfunction.


Check the dialing mode of your telephone by pressing any button on your telephone while holding the receiver off the base unit. If you hear a tone sound, your dialing mode is the tone mode. If you hear a click sound, your dialing mode is the pulse mode. If you have a rotary-type telephone, your dialing mode is also the pulse mode.



### ***Set the Dialing Mode for the Modem.***

- 1 Click the Start button, point to Settings, and then point to Control Panel.
- 2 Click the Modems icon in the Control Panel. The Modems Properties dialog box displays (Windows Me).  
Click the Phone and Modem Options icon in the Control Panel. The Phone and Modem Options dialog box displays (Windows 2000).
- 3 Click Dialing Properties. The Dialing Properties dialog box displays (Windows Me).  
At the Dialing Rules tab, and then click Edit. The Edit Location dialog box displays (Windows 2000).
- 4 Select Tone or Pulse from Dialing Mode (Windows Me and Windows 2000).
- 5 Click OK to close the Dialing Properties or Edit Location dialog box and then click OK to close the Modems Properties or Phone and Modem Options dialog box.
- 6 Open the modular jack cover.


### ***Opening the Modular Jack Cover***



### ***Connect to the Telephone Line***


Connect the telephone cord to the line jack on the side of the notebook until it clicks into place.


### **Connecting Telephone Cord to Line Jack**



If your telephone has two modular jacks, connect it as illustrated below.

### **Telephone with Two Modular Jacks**



 **Note:** When you complete the connections, you must use your communication software to adjust the settings for your telephone, fax, and communication methods. For details on adjusting settings, refer to your communications software manual.

### **Notes on the Telephone Line**

- ☐ The internal fax modem can be connected to the subscriber telephone line. Do not connect it to the PBX (Private Branch Exchange). Connecting to the PBX may cause a failure or fire.
- ☐ Some PBXs may use the same electric requirements as the subscriber telephone line of the local telephone company. Ask the manufacturer of your PBX or your PBX maintenance agent for compatibility.

- ❑ The internal modem of your notebook is set to hang up if the called party does not answer within 60 seconds. You may change this length to less than 30 seconds, which, however, may prevent a connection from being established due to some delays caused by the telephone switch. It is advised to set the length to 30 seconds or more.
- ❑ If your Internet service provider supports V.90 or 56K, communications of up to 53 Kbps are available. This may vary, depending on the telephone line condition.
- ❑ If you use a splitter to branch the telephone line, the internal fax modem may not operate successfully.
- ❑ Select the appropriate mode adopted in your country. You can select it from the Modem Properties dialog box.


## ***Connecting to the Local Area Network (LAN)***

For the detailed settings and devices needed to connect to the network, please ask your system manager.

### ***Using Ethernet to Connect to a Network***

You can exchange data with other devices on a network by connecting your notebook to the location's Local Area Network (LAN). To connect the notebook to a network, you need a network PC card. For more information on using PC cards, see "Using PC Cards" on page 47 of the User Guide. Consult the network administrator to find out about the accessory settings required to access the network.

#### ***Connecting to LAN***



## ***Setting Up Your Ethernet Connection***

### ***To connect to the network (Windows Me):***

- 1 Right-click My Network Places and select Properties.
- 2 Click the Identification tab and type in the computer name, workgroup, and computer description.

### ***To connect to the network (Windows 2000):***

- 1 Right-click My Network Places and select Properties. The Network and Dial-up Connections dialog box displays.
- 2 Click Make a New Connection. The Network Connection Wizard displays. Follow the online instructions to connect to the network.

### ***To set network components (Windows Me):***


- 1 Right-click My Network Places and select Properties.
- 2 Click the Configuration tab. This will give you access to a listing of installed network components. If you do not see the component you desire, click Add and follow the on-screen installation instructions.

### ***To set network components (Windows 2000):***

- 1 Right-click My Network Places and select Properties. The Network and Dial-up Connections dialog box displays.
- 2 Click the Add New Components hyperlink. This will give you access to add or remove network components. Follow the on-screen installation instructions.


## Connecting a Universal Serial Bus (USB) Device

You can connect a USB device, such as a USB mouse, floppy disk drive, or printer\* to your computer.


 You can use the optional Sony USB mouse (PCGA-UMS1 series) or the optional Sony floppy disk drive (PCGA-UFD5) with this notebook. Plug the USB device into the USB port. You do not need to turn off your computer.

See the manual that came with your USB device for more information on installation and use.

### To Connect a USB Device

Use the  symbol to locate the USB connector on the left side of the computer. Plug the USB cable into this port.

#### Connecting a USB Device



\* You must use a USB cable (optional) to connect a printer to your computer.


## Connecting an External Display

You can connect your notebook to a monitor or projector.

### To Connect a Monitor

Use the VGA Adapter Port on the left side of the notebook. Plug the display adapter (supplied) into this port. If necessary, plug one end of the display's power cord into the display, and the other end into an AC outlet.

#### Connecting a Monitor




 See the manual that came with your monitor for more information on installation and use.

### To Connect a Projector

You can use a projector, such as the Sony LCD Projector, as an external display.

## Connecting a Projector




 See the manual that came with your projector for more information on installation and use.

### To remove the display adapter

Press both sides of the display adapter connector and unplug it from the notebook.

### To select a display

When you connect an external display to your notebook, you can press Fn+F7 to toggle the output between the Liquid Crystal Display (LCD), the external monitor, or both devices.


 See “Selecting the Display Mode” in the online manual *Customizing Your VAIO® Notebook* for more information.

## ***Recording from a Microphone or Audio Equipment***

You can record messages, memos, or other recordings in analog by connecting a microphone or other audio equipment to the Microphone/Line in connector of your notebook and then switching the connector functionality. The Microphone/Line in connector is for both MIC IN (monaural) and LINE IN (stereo).

### ***Switching the connector functionality***


To switch the Microphone/Line in connector for use with a microphone or an audio device:

- 1 Double-click  on the task tray located in the lower right corner of the Desktop window. The Volume Control window appears.
- 2 From the Options menu, click Properties. The Properties window appears.
- 3 In the Adjust Volume panel, select Recording, and then click OK. The Recording Control window appears.
- 4 Select either Microphone or Line.


 When you are recording using a microphone, select Microphone. If you are recording using other audio equipment, select Line.

### ***Adjusting sound volume in the Recording Control window***

When Microphone or Line are not displayed in the Recording Control window, from the Options menu, click Properties, click the item you want to display in Control, and then click OK.

 You can only adjust the recording volume in the Recording Control window in step 3. If you adjust the volume in step 1, the adjustment is only effective for playing sound. It does not adjust the volume for recording sound.

### ***To increase the sound of the microphone:***

- 1 Double-click  on the task tray located in the lower right corner of the Desktop window. If Microphone is not displayed, from the Options menu




click Properties, select Microphone from the Control panel, and then click OK.

- 2 From the Microphone panel, click Advanced. The Advanced Controls for Microphones dialog box displays.
- 3 Click Mic 20dB in Other Controls, and then click Close.

### ***Adjusting volume***

You can adjust the sound device volume for playing or recording.

To adjust the volume when playing, double-click  in the task tray located in the bottom right corner of the Desktop window. The Volume Control window displays.


To adjust the sound of other devices, from the Option menu, click Properties. In the Volume Adjust window, select Playback, and click the check box of the item you want to display in Control. Click OK.

<b><i>Sound device</i></b>	<b><i>Function</i></b>
<b><i>Volume Control</i></b>	Adjust the sound level from the speakers or headphones.
<b><i>WAVE</i></b>	Adjust the wavfile sound or the effected sound of Windows.
<b><i>PC Beep</i></b>	Adjust the beep sound when inserting or removing the PC card, etc.
<b><i>Telephone</i></b>	Adjust the modem or telephone line volume.
<b><i>Microphone1</i></b>	Adjust the internal or external microphone volume.
<b><i>Line</i></b>	Adjust the audio equipment volume.
<b><i>CD Audio</i></b>	Adjust the volume of the CD in the CD-ROM drive (PCGA-CD51/A is optional).
<b><i>MIDI2</i></b>	Adjust the MIDI sound.
<b><i>3D Wide</i></b>	Widen the sound effect. (Effective for games, etc.)

### ***To make the microphone echo***


- 1 From the Start menu, select Settings, and click Control Panel. In the Control panel, double-click YAMAHA DS-XG.
- 2 Select the Echo tab.

- 3 Click Effective, you can also customize the setting by choosing options such as Time.
- 4 Click OK.

 When recording or using microphone echo, some software options may not be available.

### ***To effect the MIDI sound:***

- 1 From the Start menu, select Settings, and then select Control Panel.
- 2 Click the YAMAHA DS-XG Audio Config icon. (If you do not see the icon that you are looking for, click “Display all the options of the Control Panel.”)
- 3 Select the Synthesizer tab.
- 4 Select the desired effect, and then click OK.

To adjust the sound volume when recording, double-click  in the task tray located in the lower right corner of the Desktop window.

- 1 From the Options menu, select Properties.
- 2 In the Volume Adjust window, select Recording, and then click OK. The Recording Control window appears.

You can adjust the sound using the Smart Label software (included) or the sound recorder.

<b><i>Sound device</i></b>	<b><i>Function</i></b>
<b><i>Telephony</i></b>	Adjust the modem or telephone line sound.
<b><i>Microphone</i></b>	Adjust the internal or external microphone sound.
<b><i>Line</i></b>	Adjust the audio equipment sound volume.
<b><i>CD Audio</i></b>	Adjust the digital sound volume of CD of the optional CD-ROM drive (PCGA-CD51/A).
<b><i>Stereo Out</i></b>	Adjust the sound from Volume Control. The bass boost function is not enabled.

## Adding Memory

By adding memory to your notebook, you can increase the speed of data processing, especially when several software applications are open at the same time.



**Sony recommends memory upgrades be performed by an authorized Sony Service Center or Sony authorized agent. To find the nearest center or agent, see <http://www.sony.com/pcsupport>.**



**The following procedures assume familiarity with the general terminology associated with personal notebooks and with the safety practices and regulatory compliance required for using and modifying electronic equipment.**

- ❑ The components inside the notebook are extremely delicate. To avoid damage to the notebook, proceed carefully when removing or installing memory modules.
- ❑ You can add up to 256 MB of memory on the PCG-SR17/PCG-SR17K by installing optional memory modules. To upgrade memory, use only a PC-100 SDRAM microDIMM with gold lead contacts.
- ❑ Memory modules and other Sony notebook supplies, accessories, and peripherals can be purchased from an authorized Sony dealer, or by contacting Sony at <http://vaio.sonystyle.com/>.

### Installing a Memory Module

The notebook is equipped with two memory slots. You can expand the memory in both slots up to a maximum of 256 MB.

The PCG-SR17/PCG-SR17K has 64 MB of memory preinstalled in each of the slots for a total of 128 MB. You can remove those modules and replace them with 128 MB in each slot for a total of 256MB.



**Warning: Be careful when adding memory. Mistakes when installing or removing a memory module may cause a malfunction.**

**Observe proper safety precautions when installing modules in your notebook.**


To avoid damage to a memory module from static electricity, follow these guidelines:


- ❑ Avoid handling and installing memory modules where static electricity can easily be generated (for example, on a thick carpet.)
- ❑ Before you pick up or touch a memory module, ground yourself by touching a metal surface with your hand. This will discharge static electricity that has accumulated on your body.
- ❑ Do not remove a memory module from its protective package until you are ready to install it. The package protects the module from electrostatic discharge.
- ❑ Store a memory module in its protective package or wrap it in aluminum foil.

### ***To install a Memory Module***

- 1 Turn off the notebook and all peripheral devices.
- 2 Disconnect the power cord and all cables from the notebook, and then remove the batteries.  
The interior of the notebook becomes extremely hot during operation. Wait at least one hour for the notebook to cool down before you remove the screws.
- 3 Use a precision Phillips screwdriver that matches the size of the screw heads to remove the 6 screws marked (\*) on the bottom of the notebook.


### ***Location of Screws***



 To avoid damaging the notebook, do not remove or loosen any other screws.


- 4 Open the display panel, raise the palm rest toward you, turn it over, and then set it gently on the keyboard. When you turn the palm rest over, gently perform the action in order to avoid breaking the attached cable.

### ***Opening the Display Panel***




- 5 Before you remove the module from its package, touch a metal part of the notebook to discharge any static electricity accumulated on your body. Remove the module from its protective package.
- 6 Install the memory module by holding the module edge connector pointing down with the notch on the right, and then insert it diagonally into an empty slot.

### ***A Memory Module***



Lower the memory module until it clicks into place on both ends.

## Installing a Memory Module




**Do not touch any part of the motherboard or the other components inside the notebook.**

- 7 Return the palm rest to its original position by aligning it with the notch on the keyboard and then setting it on the keyboard.

Handle the palm rest gently to avoid breaking the attached cable.

### ***Aligning the Palm Rest***



- 8 Close the display panel and replace the six (6) screws on the bottom of the notebook.
- 9 Use the Phillips (+) screwdriver to tighten all six screws at the locations shown below.

### ***Removing a Memory Module***

- 1 Turn off the notebook and all peripheral devices. Disconnect the power cord and all cables from the notebook, and then remove the battery.
- 2 Perform Steps 2 and 3 for “Installing a Memory Module.” The notebook interior becomes extremely hot during operation. Wait about one hour for the notebook to cool down before you remove the screws.


### 3 Remove the memory module.

Before you handle the memory module, touch a metal part of the notebook to discharge any static electricity accumulated on your body.

Carefully press down on the release tabs on either end of the memory module at the same time.

Pull out the memory module in the direction of the arrow.

#### ***Removing a Memory Module***



Perform Steps 6 and 7 for “Installing a Memory Module.”

#### ***Confirming Added Memory Capacity***

- 1 Turn on the notebook.
- 2 Click the Start button, point to VAIO, and then click Sony Notebook Setup.
- 3 Click the About This Notebook tab. Check the System Memory displayed in the left panel to confirm that the correct memory amount is displayed.

If the memory amount on the display is not correct, shut down the system, turn off the notebook, and repeat the installation procedures.



## Sony Notebook Setup Dialog Box



# About the Software on Your Computer

Your VAIO® notebook is ready to help you work, play, learn, and communicate as soon as you turn it on. This section gives you an overview of the activities you can perform with your software titles. For support information, see “For Answers to Your Software Questions” on page 96.

## **Adobe Acrobat Reader®**

*Adobe Systems Inc.*

Acrobat Reader software allows you to view, navigate, and print electronic documents in Adobe Portable Document Format (PDF), an open file format that is intended to preserve the fidelity of documents created on all major computer platforms.

## **Adobe PhotoDeluxe® Home Edition**

*Adobe Systems Inc.*

Create amazing photo effects with Adobe PhotoDeluxe. Without learning complex software, you can enhance, restore, and be creative with your photos. Includes built-in guided activities, stock photos, clip art and templates to assist you.

## **Adobe Premiere® LE**

*Adobe Systems Inc.*

Adobe Premiere LE offers an interface and editing tool for producing movies for video, multimedia, or the Web. View source clips and edited footage simultaneously on the monitor window. Create video clips up to three hours long with complete audio-video synchronization.

## **ArcSoft® PhotoPrinter™ 2000 Pro**

*ArcSoft, Inc.*

ArcSoft PhotoPrinter 2000 Pro is an easy-to-use, advanced printing program that lets you quickly lay out multiple images in multiple sizes on a single sheet of paper. PhotoPrinter Pro offers a wide selection of templates including landscape, portrait, free style, mixed sizes, custom templates and more. The application includes enhancement tools and special effects for improving photos while giving you the ability to add text to any image.

### **DVgate™**

*Sony Electronics Inc.*

Connect a digital video camera recorder to the i.LINK® connector and capture your own video clips and still images. You can edit the clips from your video, add others, and combine clips into new movie segments. You can also save your images in a variety of popular file formats.

### **McAfee® VirusScan®**

*Network Associates, Inc.*

Protect your computer from viruses. VirusScan can detect viruses from floppy disks, Internet downloads, e-mail attachments, intranets, shared files, CD-ROMs, and online services.

### **Media Bar™**

*Sony Electronics Inc.*

Media Bar software is your all-in-one solution for audio/video playback. Media Bar software handles all common computer multimedia formats and controls selected Sony devices. In addition to audio/video library cataloging and playlist management, Media Bar software includes digital video quality control and effects features. Media Bar software seamlessly integrates a variety of new media formats with an easy-to-use software interface.

### **Microsoft® Internet Explorer**

*Microsoft Corporation*

Internet Explorer delivers the web the way you want it. It is safe, easy to use, and you can personalize how you access the web. Outlook Express and other tools in Internet Explorer also help you have a great experience when you are on the web.

### **Microsoft® Word 2000**

*Microsoft Corporation*

Microsoft Word 2000 makes it easy to create common Web, e-mail, and print documents for use around the world. It embraces HTML as a first-class file format and extends this software's ease-of-use to the Web and e-mail. Word 2000 also extends that ease-of-use to international users, making it simple to create multilingual documents.

### **MovieShaker™**

*Sony Electronics Inc.*

Sony's original MovieShaker software creates personal movies that have transitions, background music and text. Just import your video clips and "shake" with the click of a mouse. Your personal movies are easy to create and fun to share with family and friends.

### **Netscape Communicator®**

*Netscape Communications*

Netscape Communicator is an all-in-one Internet tool that makes it easy to browse the web, send Internet e-mail, chat, read newsgroups and compose great web documents.

### **OpenMG™ Jukebox**

*Sony Electronics Inc.*

OpenMG Jukebox software enables you to import digital audio files by downloading audio files from Electronic Music Distribution (EMD) services over digital networks, such as the Internet. You can record audio CDs onto your hard drive in a variety of formats.

### **PictureGear™**

*Sony Electronics Inc.*

This image management software displays images from your hard drive, a Sony Digital Still Camera, or a Sony Mavica® Camera. The images appear in a convenient light-table format, so that you can easily view the contents of an entire folder.

### **Quicken® 2000 Basic**

*Intuit, Inc.*

Quicken is a fast, easy way to organize your finances. Quicken works just like your checkbook, so it is easy to learn and use. Quicken manages all your finances, bank accounts, credit cards, investments, and loans. You can even pay your bills online.

### **Smart Capture**

*Sony Electronics Inc.*

Smart Capture is a fun new way to send multimedia messages via e-mail. Smart Capture manages the i.LINK connection between your computer and a Sony Digital Handycam® camcorder that supports the i.LINK interface. It allows you to capture compressed video or still images that you can save or share via e-mail. A smart solution to computer, digital audio/video and network convergence.

### **Sound Forge® (Windows 2000 only)**

*Sonic Foundry*

Sound Forge XP allows you to put powerful audio processing tools and effects to work on your notebook. Simply cut, copy, and paste your way to striking multimedia files for use in everything from Web pages to desktop presentations.

### **Smart Connect (Windows 2000 only)**

*Sony Electronics Inc.*

Smart Connect allows you to use an i.LINK® cable (optional) to connect your VAIO computer to another VAIO computer that supports Smart Connect. You can then use one computer to copy, delete, and edit files on the other computer. You can also print from a printer attached to either computer.

### **VAIO Action Setup**

*Sony Electronics Inc.*

VAIO Action Setup manages the settings for your computer's Shortcut keys and i.LINK interface.

### **VAIO Support Agent**

*Sony Electronics Inc.*

VAIO Support Agent.

## ***About Your Recovery CDs***

### **Application Recovery CD(s)**

*Sony Electronics*

This program allows you to reinstall individual applications and device drivers. Use it to restore corrupted or erased files.

### **System Recovery CD(s)**

*Sony Electronics*

This program allows you to restore the software titles that shipped with your computer if they become corrupted or are erased accidentally. It can be used only to restore the hard disk of the Sony computer you purchased.

## ***Supplementary Information***


### ***Recovering Microsoft® Word 2000***

If you recover your operating system using the System Recovery CD, Microsoft Word 2000 will not be recovered. Use the supplied Word 2000 CD-ROM to recover this application.


## Movie Shaker

This application can be used to create fun and innovative movies without any knowledge of film editing. In a few simple steps, motion pictures can be combined with special effects, still images (pictures), and music files and then saved in a format most computers can play.

### Main Window



### Importing Images and Sound Clips

- 1 Click .
- 2 Find the file you want to add.
- 3 Select the file.
- 4 Click Open. The file is added to the Clip tray.

### Create a Movie using Shaker


After adding clip(s) to the Clip tray, you can create a short movie using the Shaker feature. Shaker randomly select clips from the Clip tray to create a 30-second scene.

- 1 Click the Shake tab.
- 2 Select a mood by clicking a face in the Shaker tray.

### **Shaker Tray**



- 3 Click **Shake !**. A thirty second scene is automatically generated and saved to the Product tray.
- 4 To preview, switch the Work Panel to Product tray mode and press play.

 Scenes created with Shaker begin with black frame and after processing are placed in the first available slot on the Product tray.

## **Editing Clips and Scenes**


You can edit your movie by adding effects and text, adjusting the color and contrast, and modifying the length of clips.

### **Working Panel**



### ***Adding effects to a scene or a clip***

- 1 Double-click the clip or scene to move it to the Working Panel.
- 2 Select the Effects tab from the Editing tray.
- 3 Drag and drop the Effect you want to add from the Effects tray to the Effects palette on the Working Panel.

 To preview an Effect, click on the clip in the Working panel monitor. Your clip displays with the new effect on the Effect tray monitor.


- 4 See help for instructions on adjusting effect duration and replaying clips/scenes.

### ***Saving a Movie***

- 1 Verify that the clip(s) you want to save is on the Product tray. See Help for more details on saving movies.
- 2 Click Export.
- 3 Select the format in which you want the document to be saved.
- 4 Click Next.
- 5 Locate the folder to which you want the file saved.
- 6 Name the file.
- 7 Click Save.



**Exporting movies may take a long time to complete—Save movie as DV (Digital Video) takes the longest and Quick-Save is the fastest.**

 For DV playback and smooth video playback, we recommend the following resolution/refresh rates: 1024×768/75Hz or lower.



## ***PictureGear™***

PictureGear is a digital image management application that allows you to see all the images stored in any directory on your computer. Thumbnail views provide quick reminders of your pictures. Brighten, contrast, enhance, resize, crop, and color-correct your pictures. Create panoramic views, animations, screen savers, wallpaper, still pictures from MPEG, and even html photo albums.

### ***Managing Your Pictures***

Use the collection feature to manage your pictures.

- 1 Click the Folder tab and browse to locate your pictures.
- 2 Select the pictures you want to have in a collection.
- 3 From Collection menu, select Create New Collection.
- 4 Enter a name for the collection and then click OK.

### ***Creating a Photo Album***


- 1 Select the pictures you want to use to make an album.
- 2 From the Utilities menu, select Album Maker.
- 3 Choose the type of Album you want and click OK.
- 4 Now add more pictures, frames, text, and effects.
- 5 When you are finished, select Create Album in File menu or click the Create Album icon on the toolbar.
- 6 Designate the folder where you want to save the Album.
- 7 Enter the Target Album name, select Thumbnails and click OK.
- 8 The new album can be viewed using most internet browsers.

### ***Using Panorama Maker***

Panorama Maker stitches a group of still images into a 360 degree panoramic picture. The source images should be the same size and overlap 20%.

How to stitch a panoramic picture:

- 1 Gather the source images into the same folder or collection.
- 2 Select the images you want to use.

 We recommend 12 landscaped or 16 portrait pictures.

- 3 From the Utilities menu select Panorama Maker.
- 4 Select the correct lens and click OK. (If 35mm lens is selected, the prompt does not appear; to select a different lens, click the lens icon.)
- 5 Click the panoramic icon, near the bottom of the window.
- 6 Click Full Stitch.

### ***Making Still Images and Panoramic from MPEG***

- 1 Select the MPEG file.
- 2 From the Movie/Sound menu, select Scene break down.
- 3 Then select Movie Stitch, to create a panoramic picture.

## ***For Answers to Your Software Questions***

### ***Acrobat® Reader, Adobe PhotoDeluxe® Home Edition, Adobe Premiere® LE (Adobe Systems Incorporated)***

---

Web site	<a href="http://www.adobe.com/">http://www.adobe.com/</a>
phone	206-628-2746 (fee-based support)
fax	206-628-5737
e-mail	<a href="mailto:techdocs@adobe.com">techdocs@adobe.com</a>
hours	M-F, 6 AM-5 PM PT

---

### ***McAfee® VirusScan® (Network Associates, Inc.)***

---

Web site	<a href="http://support.mcafee.com">http://support.mcafee.com</a>
phone	408-988-3832
e-mail	<a href="mailto:cybr@nai.com">cybr@nai.com</a>
hours	M-F 9AM-5PM Central Time

---

### ***Netscape Communicator® (Netscape Communications Corp.)***

---

Web site	<a href="http://www.netscape.com/">http://www.netscape.com/</a>
phone	888-4SONYPC (888-476-6972)*
hours	7 days a week, 24 hours a day

---

\* Support from 1-888-4SONYPC is free of charge for 90 days after the original date of purchase.

### ***PhotoPrinter™ 2000 Pro (ArcSoft, Inc.)***

---

Web site(s)	<a href="http://www.arcsoft.com">http://www.arcsoft.com</a> <a href="http://www.photoisland.com">http://www.photoisland.com</a>
phone	510-440-9901
fax	510-440-1270
e-mail	<a href="mailto:techsupport@arcsoft.com">techsupport@arcsoft.com</a>
hours	M-F, 8:30 AM-5:30 PM PT

---

***Sound Forge® (Sonic Foundry)***

Web site	<a href="http://www.sonicfoundry.com">http://www.sonicfoundry.com</a>
phone	608-256-5555
fax	608-256-7300
e-mail	<a href="mailto:support@sonicfoundry.com">support@sonicfoundry.com</a>
hours	M-F, 8 AM- 7 PM CT

***Quicken® 2000 (Intuit Inc.)***

Web site	<a href="http://www.intuit.com/support">http://www.intuit.com/support</a>
phone	900-555-4688
hours	7 days a week, 24 hours a day

***Windows® 2000 Operating System, Windows® Millennium Edition Operating System, Internet Explorer, Word 2000 (Microsoft Corporation)***

Web site	<a href="http://www.microsoft.com/support/">http://www.microsoft.com/support/</a>
phone	888-4SONYPC (888-476-6972)*
hours	7 days a week, 24 hours a day

\* Support from 1-888-4SONYPC is free of charge for 90 days after the original date of purchase.

***Sony Service Center***

For the Sony Service Center nearest you, call 1-888-4SONYPC (1-888-476-6972) or find Sony Customer Service on the Web at <http://www.sony.com/pcsupport/>.



# *Using the System and Application Recovery CDs*

The following sections describe how to use the System Recovery and Application Recovery utilities. You need to connect the optional CD-ROM drive (PCGA-CD51/A), or the DVD drive (PCGA-DVD51/A) drive, to use the System and Application Recovery CDs. (Windows Me does not support PCGA-CDRW51.)

## ***Using the System Recovery CD(s)***

You can reinstall software titles that shipped with your computer if they are corrupted or erased. You may not need to recover the entire contents of your hard drive. If you experience a problem with your computer, reinstalling an individual device driver or software title may correct the problem. Use the Application Recovery CDs to reinstall individual applications or device drivers. See “Using the Application Recovery CD(s)” on page 101.

The System Recovery CD contains a backup copy of all the software originally installed on your hard disk drive. It can be used only to recover the hard disk of the notebook computer you purchased.

The System Recovery utility gives you two options:

- ☐ **Full Restore without Format** — restores all the software titles that originally came with your computer without formatting the hard disk.



If you recover your operating system using the System Recovery CD, Microsoft Word 2000 will not be recovered. Use the supplied Word 2000 CD-ROM to recover this application.

- ☐ **Full Restore with Format** — formats the hard disk drive and then restores all the original software.



**If you choose the Full Restore with Format option, your hard disk will be formatted, which removes all the information on the hard disk drive. You will lose any software you have installed and any other files you have created since you started to use your computer. This means you will have to reinstall any applications that were not included with the computer when you purchased it. If you choose the Full Restore without Format option, you may need to reinstall applications that were not included with the computer when you purchased it. If you have any questions on using the System Recovery CD, contact Sony Customer Support.**

### ***To use the System Recovery CD(s)***




The optional CD-ROM drive (PCGA-CD51/A) or the DVD drive (PCGA-DVD51/A) must be connected to the computer to use the System Recovery CD.

If you use the PCGA-51/A, connect the AC adapter supplied with the drive and power it on.

If you use the PCGA-DVD51/A, do not connect the AC adapter supplied with the drive.

You need to complete the Windows registration process when you use the System Recovery CD. Make sure you have the product ID number located on the cover of your Microsoft Windows *Getting Started* manual. You will need this number to complete the recovery process.

- 1 Insert the Sony System Recovery CD in the CD-ROM drive.
- 2 Shut down your computer as described in “Shutting Down Your Computer” on page 32.
- 3 Wait four seconds and then turn on your computer.
- 4 Click OK to signify you have read and accept the Microsoft End-User License Agreement.
- 5 When the System Recovery menu appears, follow the on-screen instructions to complete the recovery process.

 Your system may include one or two System Recovery CDs. If you have two System Recovery CDs, insert the first CD to run the System Recovery program. You are prompted to insert the second CD once the information from the first CD has been installed.

The recovery process takes 30 to 60 minutes to complete.

After recovering your system using the SRCD, you may be prompted to insert your ARCD after restarting Windows®. Insert the ARCD to automatically complete recovery of your system.

### ***If your computer does not start from the Recovery CD***

- 1 Slide the power switch forward and hold it for more than four seconds to turn off the computer.
- 2 Turn on the computer and press the F2 key when the Sony logo appears. The BIOS setup menu screen appears.
- 3 Press the arrow keys to select the Exit menu.
- 4 Press the arrow keys to select Get Default Values and then press the Enter key. The message “Load default configuration now?” appears.
- 5 Check that Yes is selected, then press the Enter key.
- 6 Press the arrow keys to select Exit (Save Changes) and then press the Enter key. The message “Save configuration changes and exit now?” appears.
- 7 Check that Yes is selected, then press the Enter key. The computer restarts from the Recovery CD.

### ***Using the Application Recovery CD(s)***

The Application Recovery CDs allow you to reinstall individual applications and device drivers if they are corrupted or accidentally erased. Reinstalling an individual device driver or software title may correct a problem you are experiencing with your computer, and you may not need to recover the entire contents of your hard drive. If you do need to reinstall all the software titles that shipped with your computer, use the System Recovery CD. See “Using the System Recovery CD(s)” on page 99.




 You must be in Windows to run the Application Recovery CDs. If you have any questions on using the Application Recovery CDs, contact Sony Customer Support.

Some applications on the Application Recovery CDs must be decompressed before the installation process begins. Your screen does not change while the files are decompressed. The time to decompress an application varies and may be as long as 30 minutes.

### ***To use the Application Recovery CD(s)***

- 1 Turn on your computer. If your computer is already on, close all applications.
- 2 When the Windows desktop appears, insert the first Sony Application Recovery CD in the CD-ROM drive. The Application Recovery utility loads automatically.
- 3 When the Application Recovery menu appears, follow the on-screen instructions to complete the recovery process.

 Your system may include one or two Application Recovery CDs. If you have two Application Recovery CDs, insert the first CD to run the Application Recovery program. You may be prompted to insert the second CD, depending on the application you wish to restore.

# Troubleshooting

This section describes how to solve common problems you may encounter when using your notebook. Many problems have simple solutions, so try these suggestions before you contact Sony PC Support (<http://www.sony.com/pcsupport>).

## ***Troubleshooting your notebook***

(Windows Me only) When starting your notebook for the first time, the VAIO InitManager dialog box will appear. Please select “OK” to begin initial setup. If you do not execute the initial setup, you cannot use part of VAIO original hardware functions such as Jog Dial, Power Management tool, scroll function of touchpad, and keyboard shortcut key function combined with the Fn key.

### ***My notebook does not start***

- ☐ Check that the notebook is plugged into a power source and that it is turned on. Check that the power indicator on the front panel of the notebook indicates that the power is on.
- ☐ Check that the battery packs are inserted properly and that they are charged.
- ☐ Make sure there is no diskette in the floppy disk drive.
- ☐ Confirm that the power cord and all cables are connected firmly, as described in “To Connect a USB Device” on page 74.
- ☐ If you plugged the notebook into a power strip or UPS, make sure the power strip or UPS is turned on and working.
- ☐ If you are using an external display, check that it is plugged into a power source and turned on. Check that the brightness and contrast controls are adjusted correctly. See the manual that came with your display for details.
- ☐ Moisture condensation may have occurred. Do not use the notebook for at least one hour and then turn on the notebook.
- ☐ Take the battery pack off the notebook, unplug the power cord and plug it again, then turn on the power.

*My notebook starts, but my system doesn't start properly*

- ❑ When the internal backup battery is low on power, it may not start your system properly. The message “Press <F1> to resume, <F2> to setup” appears at the bottom of the screen. Follow these steps:
  - 1 Press F2. The BIOS Setup menu appears.
  - 2 Set the date (month/day/year). Press Enter.
  - 3 Press ↓ to select System Time, then set the time (hour: minute: second). Press Enter.
  - 4 Press → to select Exit, then press ↓ to select Get Default Values. The message “Load default configuration now?” appears.
  - 5 Select Yes and press Enter.
  - 6 Select Exit (Save Changes), and then press Enter. The message “Save Configuration changes and exit now?” appears.
  - 7 Select Yes, and then press Enter. The notebook restarts.

*My notebook starts, but the message “Operating system not found” appears and Windows does not start*

- ❑ Make sure there is no diskette in the floppy disk drive (non-bootable).
- ❑ If a non-bootable diskette is in the drive, follow these steps:
  - 1 Turn off the notebook, and then remove the diskette.
  - 2 Restart the notebook and confirm that Windows starts properly.
- ❑ If Windows still does not start, follow the steps below to initialize the BIOS:
  - 1 Remove any diskette from the floppy disk drive.
  - 2 Remove any peripheral devices connected to the notebook.
  - 3 Turn off the notebook and then turn it on.
  - 4 Press the F2 key when the Sony logo appears. The BIOS setup menu screen appears.
  - 5 Press the directional arrow keys to select the Exit menu.
  - 6 Press the arrow keys to select “Get Default Values” and then press Enter. The message “Load default configuration now?” appears.

- 7 Select Yes, then press Enter.
- 8 Use the directional arrow keys to select “Exit” (Save Changes), and then press Enter. The message “Save configuration changes and exit now?” appears.
- 9 Select Yes, then press Enter. The notebook restarts.

If your notebook continues to display the message “Operating system not found”, and Windows does not start, contact Sony Customer Support.

### *My notebook stops responding or does not shut down*

It is best to shut down your notebook using the Shut Down command on the Windows Start menu. Using other methods, including those listed here, may result in loss of unsaved data.

- ☐ Try restarting the notebook. On the Windows taskbar, click the Start button, click Shut Down, and then click Restart.
- ☐ If you cannot restart as described in the preceding step, you can restart the notebook by pressing Ctrl+Alt+Delete.
- ☐ If the previous step does not work, press and hold the power button for at least four seconds. This turns off the power.
- ☐ If your notebook stops responding while playing a CD or DVD, stop the CD/DVD, and restart the notebook by pressing Ctrl+Alt+Delete.
- ☐ Unplug the notebook from the AC adapter and remove the battery pack from your notebook.



Pressing Ctrl+Alt+Delete or turning off the notebook with the power switch may result in data loss in files that are currently open.

### *My notebook does not enter the power saving mode I selected. (Windows Me only)*

- ☐ Click Start, point to Program, point to Accessories, point to System Tools, and then click System Information.  
The Help and Support window appears.
- ☐ Click System Configuration Utility under the Tools menu.
- ☐ Click the Advanced button on the General tab, and Confirm the following information:

- 1 Enable Deep Sleep is selected with a checkmark.
- 2 The message “Standby function is enabled” is displayed. If the message reads “Standby function is disabled”, click the Enable button.
- 3 The message “Hibernation feature is enabled” is displayed. If the message reads “Hibernation feature is disabled”, click the Enable button.
- 4 Click OK and restart your notebook.

***My system enters System Idle mode when System Suspend mode has been selected***

- ☐ If you are connecting an optical disc drive with a PC card, disconnect it by stopping the PC card. Use the Sony Notebook Setup utility to disable devices that you are not currently using. See “Removing a PC card” for more information.
- ☐ Make sure the PC Card is compatible with your notebook’s Windows® operating system.



(Windows 2000 only) When the notebook enters and returns from a power saving mode after removing the optical drive, the message "Unsafe Removal of Device" may appear and the device name is shown listed as "Secondary IDE Channel. Click OK.

***The Power Management setting is not responding***

Your notebook’s operating system may become unstable if a lower power state, such as system hibernation is initiated and then changed before the notebook completely enters the lower power state. To restore the notebook to its normal operating stability:

- ☐ Close all open applications.
- ☐ Push and hold the power button for four seconds or longer to shut down the notebook.

***The sound of my notebook’s fan is too loud***

Use the PowerPanel utility to change the Thermal Control Strategy setting to Quiet. This setting slows down the CPU speed. See PowerPanel Help for more information.

## ***Troubleshooting the LCD screen***

### ***My LCD screen is blank***

- ☐ Check that the notebook is plugged into a power source and that it is turned on.
- ☐ Check that the power indicator on the notebook is on.
- ☐ Check that the battery pack(s) is inserted properly and that they are charged.
- ☐ The notebook may be in LCD (Video) Standby mode. Press any key to activate the screen.
- ☐ The display mode may be set to external display mode. Press and hold the Fn key while pressing F7 several times.

### ***My LCD screen continues to show the previous screen. (Windows Me only)***

Press the Windows key and D key twice to refresh the screen.

### ***The image on my connected external display is not centered or sized properly***

Use the controls on your external display to adjust the image. See the manual that came with your display for more information.

### ***I want to change the video resolution of my display***

You can use independent controls to change the video resolution of your display.

- ☐ Click Start, point to Settings, point to Control Panel, and then click the Display icon.  
The Display Properties dialog box appears.
- ☐ Click on the Settings tab.
- ☐ Move the Screen Area slider to change your video resolution.

## ***Troubleshooting the mouse and touchpad***

### ***My mouse does not work***

- ☐ If you are using an external mouse, check that the mouse is plugged into the mouse connector. See “To Connect a USB Device” on page74 for details.
- ☐ If you connected an external mouse while your notebook is on, you must restart your notebook.

- ❑ If you are using an optional Sony USB mouse PCGA-UMS1, check that the mouse is plugged into the USB connector.

***My touchpad does not work properly***

- ❑ You may have disabled the touchpad without a mouse being connected to the notebook. You must restart the notebook to make the touchpad work again.
- ❑ If your touchpad is interpreting a single tap as a double-click, you must adjust the button assignments. Follow these steps:
  - 1 Click Start, point to Control Panel, and then click on the Mouse icon.
  - 2 Change the button assignments in the Mouse Properties dialog box. (One of the buttons is assigned to the double-click action.)

***The pointer does not move (while using the Touchpad or Mouse)***

- ❑ Click the Start button on the Windows taskbar, and select Shut Down to display the Shut Down Windows dialog box, then press Enter.
- ❑ If you cannot turn off your notebook as described in the step above, press Ctrl+Alt+Delete to restart the notebook.
- ❑ If you cannot restart your notebook as described in the step above, press and hold the power button for more than four seconds to turn off the notebook.
- ❑ If the pointer does not move while playing a disc, press Ctrl+Alt+Delete to stop playback and restart the notebook.

***Troubleshooting drives, PC cards and peripheral devices***

***I attached a compatible device, but the icon does not appear in the My Computer window***

- ❑ The device has not been recognized. Put the notebook into System Idle mode by pressing the Fn and S keys and then resume.
- ❑ If the device is still not recognized or does not appear in the My Computer window, remove and reinsert it.

***My floppy disk drive can not write to a diskette***

- ❑ If the diskette is write-protected, disable the write-protect feature or use a diskette that is not write-protected.

- ☐ Check that the diskette is properly inserted into the floppy disk drive.

***My floppy disk drive icon doesn't appear even though it is connected***

- ☐ Click Start, point to Settings, point to Control panel, and then click System. The System Properties dialog box appears.
- ☐ Click the Device Manager tab.
- ☐ Double-click Floppy Disk Controller and then click Standard Floppy Disk Controller.
- ☐ Click Delete. The Confirmation window will appear.
- ☐ Verify that Delete From All Settings is selected and press OK.
- ☐ Click Update in the System Properties window.
- ☐ Double click Disk Drive and confirm that GENERIC NEC FLOPPY DISK is shown.

***My CD or DVD drive is not playing my CD or DVD properly***

- ☐ Make sure the optical drive is inserted correctly.
- ☐ Make sure the label of the disc is facing up.
- ☐ If the disc requires software, make sure the software is installed according to the manufacturer's instructions.
- ☐ A dirty or damaged disc may cause the notebook to stop responding while it tries to read the disc. If necessary, restart the notebook, remove the disc, and then check it for dirt or damage.
- ☐ If you see video but can not hear audio, check all of the following:
  - ☐ Check that your DVD-ROM drive does not have the mute setting enabled.
  - ☐ Check the volume setting in the audio mixer.
  - ☐ If you are using external speakers, check the volume settings, and then check the connections between your external speakers and the notebook.
  - ☐ Click Start >Control Panel > System > Device Manager. Check that the correct drivers are installed properly.
- ☐ Do not use adhesive labels to identify the CD. The label may come off while the disc is in use in the optical drive and cause the drive to malfunction.



- ❑ If a region code warning appears when you try to use your DVD-ROM drive, it may be that the DVD you are trying to play is incompatible with the DVD-ROM drive. Check the region code listing on the DVD packaging.
- ❑ Moisture condensation may have occurred. Leave the notebook idle for at least 1 hour with the notebook turned on.

***My CD-ROM or DVD-ROM drive tray does not open***

- ❑ Make sure the notebook is turned on.
- ❑ Press the Eject button on the drive.
- ❑ If the Eject button does not work, you can open the tray by inserting a sharp, pointed object into the hole to the right of the Eject button.

***I cannot use digital video (DV) devices. The message "DV equipment seems to be disconnected or turned off" appears.***

- ❑ Check that the DV device is turned on and that the cables are properly connected.
- ❑ If you are using multiple i.LINK devices, the combination of the connected devices may cause unstable operation. In this case, turn off your notebook and all connected devices. Disconnect the devices that are not in use. Check the connections for each device, then restart your notebook.

***The i.LINK-compatible devices connected to my notebook do not work***

- ❑ Use the i.LINK connector that is located on your notebook.
- ❑ If the message "There are no Digital Video devices connected to this computer, or the power is off" appears, unplug the i.LINK cable and try plugging it in again.

***My PC card is not working***

- ❑ Make sure the PC card is compatible with Microsoft® Windows®.
- ❑ Use the Sony Notebook Setup utility to disable devices you are not currently using.
- ❑ If you are using two PC cards, use the Sony Notebook Setup utility to disable the devices you are not currently using.

## ***Troubleshooting software***

### ***My software program stops responding or crashes***

Contact the software publisher or designated provider for technical support. See the “About Software” section of this manual.

### ***When I click an application icon, the message “You must insert the application CD into your CD-ROM (DVD-ROM) drive” appears and the software does not start***

- ☐ Some titles require specific files that are located on the application CD. Insert the disc and try starting the program again.
- ☐ Make sure you place the CD in the tray with the label side facing up.

### ***I hear background “noise” while using Windows Media Player to play my music CDs***

Sony suggests using the preinstalled Media Bar software to play audio CDs.

### ***I can not use the DVgate software***

If your notebook is using the Ultimate Battery Life profile for its power saving mode, you cannot use DVgate or Smart Connect software. Please select another profile.

### ***My voice-related software does not work properly***

Disable echo function of the microphone by taking the following steps:

- 1 Click Start, point to Settings, and then point to Control Panel.
  - 2 Click Yamaha DS-XG.
  - 3 Click the Echo tab and remove the checkmark. Click OK.
- ☐ Contact the software publisher or designated provider for technical support

## ***Troubleshooting the modem***

### ***My modem does not work***

- ☐ Check that the phone line is plugged into the line jack. See “Connecting a Phone Line” on page 68 for details.

- ❑ Check that the phone line is working. You can check the line by plugging in an ordinary phone and listening for a dial tone.
- ❑ Check that the phone number the program is dialing is correct.
- ❑ Check that the software you are using is compatible with the notebook's modem. (All preinstalled Sony programs are compatible.)

### ***My modem connection is slow***

Your notebook is equipped with a 56K/V.90 compatible modem. Many factors may influence modem connection speed, including telephone line noise or compatibility with telephone equipment (such as fax machines or other modems). If you think your modem is not connecting properly to other PC-based modems, fax machines, or your Internet Service Provider, check the following:

- ❑ Have your phone company check that your phone line is free from any line noise.
- ❑ If your problem is fax-related, check that there are no problems with the fax machine you are calling and that it is compatible with fax modems.
- ❑ If you are having a problem connecting with your Internet Service Provider, check that the ISP is not experiencing technical problems.
- ❑ If you have a second phone line available, try connecting the modem to that line.

## ***Troubleshooting audio***

### ***My speakers have no sound***

- ❑ If the built-in speakers are turned off, press Fn+F3 to turn on the speakers. You can also turn on the speakers using the Jog Dial control.
- ❑ If the speaker volume is turned to the minimum, press Fn+F4, and then press **↑** or **→** to increase the volume or you can use the Jog Dial control to control the volume.
- ❑ If nothing is displayed when you press Fn+F3 or Fn+F4.
  - 1 Double click System in Control Panel.
  - 2 Set the sound device to enable in Device Manager.
- ❑ If your notebook is powered by batteries, check that the battery packs are inserted properly and that they are charged.

- ❑ If you are using an application that has its own volume control, check that the volume is turned up.
- ❑ Check the volume controls in Windows®.
- ❑ If you connect external speakers, check that the speakers are properly connected and the volume is turned up. If the speakers have a mute button, make sure it is off. If the speakers are powered by batteries, check that the batteries are inserted properly and that they are charged.
- ❑ If you have connected an audio cable to the Headphone connector, disconnect the cable.

### ***My microphone does not work***

If you are using an external microphone, check that the microphone is plugged into the Microphone connector. See “Recording from a Microphone or Audio Equipment” on page 77 for details.

## ***Troubleshooting the printer***

### ***I cannot print***

- ❑ The default setting for the printer port mode is correct for most printers. If you cannot print, try changing the printer port mode. In Sony Notebook Setup, select the Printer tab. If the printer port mode is set to ECP, change it to bi-directional. If the printer port mode is set to bi-directional, change it to ECP. See “Displaying the Sony Notebook Setup Screen” in the *Customizing Your Notebook* manual for details on using Sony Notebook Setup.
- ❑ Your connected printer may not function after the computer resumes from a power saving mode. If this occurs, follow these steps to reset the printer connection:
  - ❑ Right-click the My Computer icon on the desktop, and then select Properties.
  - ❑ Click the Device Manager tab.
  - ❑ Select Refresh, and then click OK. The printer should function properly.



## Getting Help

Sony provides several support options for your Sony computer. When you have questions about your computer and the preinstalled software, check these sources for answers, in the following sequence:

---

**1      *VAIO® Notebook User Guide***

The User Guide (this manual) contains information on how to get the most from your computer, find help, and solve common problems. It also contains product specifications.

---

**2      *Customizing Your VAIO® Notebook***

The electronic document contains additional information on customizing your computer. You can access this guide from the Windows Start menu by selecting Programs and then VAIO User Manual.

---

**3      *Manuals and online help files that may accompany your preinstalled software***

Most of the manuals for preinstalled software are located on your hard disk drive as online help files. You can access the online help files from the Help menu in the specific application. A printed manual is available for some applications.

---

**4      *VAIO Support Agent***

VAIO Support Agent can be accessed from the Windows desktop. Using advanced diagnostic technology, Sony's VAIO Support Agent runs scheduled protections of your applications, network settings, and other important software settings. When your software is protected, you can use VAIO Support Agent to repair software problems by restoring your software to any of the previously protected states.

---

**5      *Sony PC Support***

Provides instant access to information on commonly encountered problems. Enter a description of your problem and the Knowledge Database searches for the corresponding solutions online. You can access the Sony PC Support at: <http://www.sony.com/pcsupport/>

---

**6      *Sony Fax-on-Demand***

This service provides you with answers to commonly asked questions. You can use this automated service to request a list of available topics and then select the topics that you want to receive. To contact the Sony fax-on-demand service, call 1-888-4SONYPC (1-888-476-6972). (Requires a fax machine or your fax software.)

---

**7      *Calling Sony Customer Support***

You can call and speak with a Sony Customer Support Representative without using your computer by calling 1-888-4SONYPC (1-888-476-6972). Software support is available free of charge for 90 days after the original date of purchase.

---



# Specifications

<b>Model</b>	<b>PCG-SR17/PCG-SR17K</b>
<b>Processor</b>	Mobile Intel® Pentium® III processor 700 MHz* featuring Intel® SpeedStep™ technology†
<b>Hard Disk Drive</b>	20 GB‡
<b>C/D Partition</b>	Approx. 40% and 60%
<b>Standard RAM</b>	128 MB SDRAM,** expandable to 256 MB††
<b>LCD Screen</b>	10.4" XGA TFT
<b>L2 Cache Memory</b>	256 KB (on Die)
<b>MPEG</b>	MPEG1 Digital Video supports full-screen playback
<b>Graphics</b>	3D accelerator with 8 MB SGRAM
<b>Sound Capabilities</b>	16-bit CD-quality stereo sound
<b>Modem</b>	V.90/K56flex compatible modem‡‡
<b>Expansion Capabilities</b>	One PCMCIA type II Slot Card Bus support
<b>Built-in Capabilities</b>	Microphone Stereo speakers Touchpad
<b>Telecommunication Capabilities</b>	Data/fax send/receive
<b>Connection Capabilities</b>	Phone line (RJ-11) i.LINK (IEEE1394) 1 USB port Microphone Jack (Mic-in/Line-in) DC In Headphone MagicGate™ <b>Memory Stick</b> VGA display
<b>Supplied Accessories</b>	Rechargeable battery AC adapter and power cord VGA adapter
<b>Power Requirements</b>	60 watts maximum (16V DC/AC 100-240V) The notebook supports 50/60Hz and 100-240V AC.



<b>Power Management</b>	Energy Star Compliant Advanced Configuration and Power Interface (ACPI)
<b>Battery</b>	Lithium-ion
<b>Dimensions</b>	10.2" (w) x 0.9" (h) x 8.2" (d) (259 mm x 23.7 mm x 209 mm) ***
<b>Weight</b>	2.99 lbs. (1.36 kg.)
<b>Operating Temperature</b>	40° F to 95° F (5° C to 35° C)
<b>Operating Humidity</b>	20% to 80% (not condensed), provided that humidity is less than 65% at 95° F (35° C), hygrometer reading of less than 84° F (29° C)
<b>Storage Temperature</b>	-4° F to 140° F (-20° C to 60° C) (temperature gradient less than 18° F (10° C)/hour)
<b>Storage Humidity</b>	10% to 90% (not condensed) provided that humidity is less than 20% at 140° F (60° C), hygrometer reading of less than 95° F (35° C)

\* MHz denotes microprocessor internal clock speed; other factors may affect application performance.

† The processor may be reduced to a lower operating speed when operating on battery power.

‡ GB means one billion bytes when referring to hard drive capacity. Accessible capacity may vary.

\*\* Your system may contain additional memory installed at the time of purchase.

†† The PCG-SR17/PCG-SR17K includes 128 MB memory.

‡‡ Maximum speed for faxing is 14.4 Kbps. Your modem is capable of downloading at 53 Kbps using 56K/V.90. Your online service or Internet Service Provider may not support this technology or operate at this speed.

\*\*\* Height measured at the thinnest point. Height at the thickest point is 1.2" (32.1mm).

Specifications are subject to change without notice.

# Index

## A

AC adapter 25, 28

AC power 25

adding

hardware 67

peripherals 67

adjusting

brightness 37

air circulation 17

Alt key 34

Application Recovery CDs 101

Applications key 34

## B

Batteries 29

battery pack 26, 29

charging 27

connector 22

indicator lights 22, 27, 36

inserting 26

loading 26

power status 27

rechargeable 25

removing 27

battery power 25

brightness

adjusting 31, 37

built-in speaker 22, 37

volume 37

buttons

Start 32

## C

cameras

digital video recorder 51

canceling commands 34

Caps Lock

indicator light 36

CD media

handling 46

CD-ROM discs

cleaning 46

handling 46

inserting 45

CD-ROM drive

closing lid 45

connecting 43, 47

using 43

CD-ROM 43

charge status indicator light 27

charging battery pack 27

choosing

power source 25

Cleaning

Your Notebook 18

- cleaning computer 18
- coin-operated telephones 69
- computer 115
  - cleaning 18
  - condensation 19
  - lithium ion battery 6
  - setting up 21
  - starting 31
  - troubleshooting 103, 111
- connecting
  - CD-ROM drive 43, 47
  - coin-operated telephones 69
  - digital video camera recorder 51
  - floppy disk drive 40
  - multiple phone lines 69
  - party phone lines 69
  - phone line 68
  - power source 25
- Connecting the CD/DVD Drive 43
- connectors
  - battery 22
  - DC In 23, 25
  - USB 40
- correction keys 33, 34
- Ctrl key 34
- cursor-movement keys 33
- customer assistance
  - support options 115
- D
- DC In 23, 25
- digital video camera recorder 51
- diskettes
  - ejecting 41
  - handling 42
  - inserting into drive 41
  - troubleshooting 108
- disposal of lithium ion battery 6
- drives 43
  - CD-ROM 43
  - floppy disk 40
- DV In/Out 24, 51
- DVD 43
- DVD media
  - handling 46
- DVD-ROM drive tray
  - troubleshooting 110
- DVgate 51, 53
- E
- Eject button 41
- ejecting
  - diskettes 41
- electronic
  - documentation 115
- Energy Star 2
- ergonomic considerations 16
- Escape key 34
- external devices
  - display 75
- F
- faxes
  - laws governing 6
- floppy disk drive

- connecting 40
- disconnecting 41, 49
- troubleshooting 108
- Fn key 34
  - combination commands 37
- function keys 34
- G
- Getting Help 115
- Guide Mode 55
- H
- handling
  - CD media 46
  - CD-ROM discs 46
  - diskettes 42
  - DVD media 46
- Handycam 51
- hard drive
  - indicator light 22, 36
- Hard Drive Partition 53
- hardware
  - online support 115
- headphone
  - connector 24
- Help
  - Getting 115
- help 115
- I
- i.LINK 24, 51
- IEEE1394 24, 51
- indicator lights 36
  - battery 22, 27, 36
  - Caps Lock 36
  - charge status 27
  - hard drive 22, 36
  - Num Lock 36
  - power 21
  - Scroll Lock 22, 36
- input devices 5
- Insert key 33, 34
- inserting
  - battery pack 26
  - diskettes into drive 41
- installing
  - hardware 67
  - peripherals 67
- interference 4, 17
- internal speaker
  - See speakers
- J
- Jog Dial 54
- K
- keyboard 22, 33–35, 37
- L
- Launcher Mode 55
- LCD 18
  - lock lever 31
  - troubleshooting 107
- lever
  - LCD 31
- Liquid Crystal Display screen
  - See LCD
- lithium ion battery

- disposal 6
- safety precautions 6

- loading
  - battery pack 26

## M

- MagicGate 57, 58
- maintenance 17
- mega-bass switch 37
- memory
  - adding 80
- Memory Stick card slot 23
- Memory Stick cards 57
- microphone 22
  - troubleshooting 114
- microphone connector 24
- modem
  - laws governing 6
  - troubleshooting 112
- moisture condensation 19
- monitor
  - switching among 37
- mouse
  - troubleshooting 107
- mouse help 39
- multiple phone lines 69

## N

- navigation keys 33
- Num Lock
  - indicator light 36
- numeric keypad area 33

## O

- online
  - help 115
- operator keys 34
- output devices 5

## P

- party phone lines 69
- PC card
  - inserting 47
  - release button 47
  - slot 47
  - slot protector 47
  - troubleshooting 111
  - Type II 47
- phone
  - connecting line 68
  - jack 68
  - laws governing 6
- Power 22
- power 36
  - indicator light 21
  - switch 31
- power saving modes 64
  - System Hibernation 37, 64
  - System Idle 37, 64
  - System Suspend 37, 64
- power sources 25
  - connecting 25
- precautions 17
- Print Screen key 34
- Printer 74

---

## R

- radio interference 4, 17
- rechargeable battery pack 25, 26
- recharging battery pack 27
- Recovery CDs 101
- removing
  - battery pack 27
  - diskettes 41
  - floppy disk drive 41, 49
- restoring data 101

## S

- screen
  - See LCD
- Scroll Lock 22
  - indicator light 36
- selecting
  - power source 25
- setting up your PC
  - support 115
- Shaker 92
- Shift key 34
- Shut Down Windows dialog box 32
- Sony Fax-on-Demand service 115
- speakers
  - built-in 22
  - troubleshooting 113
- Start button 32
- starting
  - computer 31

- startup problems 32
- switching
  - display 37
  - monitor 37
- System Hibernation mode 37, 64
- System Idle mode 37, 64
- System Recovery CD(s) 99
- System Suspend mode 37, 64

## T

- technical support
  - support options 115
- touchpad 22, 38
- troubleshooting 103
  - startup 32, 103
- turning on
  - computer 31

## TV

- interference 4
- TV interference 17

## U

- USB connector 40, 74
- USB device 74
- Using
  - Batteries 29
- Using the Jog Dial Control 56

## V

- VAIO® Action Setup 54
- ventilation 17
- video camera recorder 51

## W

### Windows

- Explorer 35

- Find window 35

- Help 35

- key 34

- key combinations 35

- Start button 32


- taskbar 32

### Windows 2000 13

### Windows 98


- taskbar 105

### 1-1. Flowchart



- P XX denotes the page that corresponds with the item referenced.
- Remember that hard disk drives are easily damaged by vibration. Always handle with care.


### 1-2. Main Electrical Parts Location Diagram






# 1-3. Removal

## 1. Keyboard Unit, Parm Assy




## 2. Touch pad, Speaker, SWX-61 Board




**Confidential**


### 3. HDD




### 4. Speaker, IFX-125 Board



## 5. DC Fan, Cooling




## 6. Main Board Assy




**Confidential**

## 7. MBX-44 Board, IFX-124 Board, DDC-3 Board, V/L Rechargeable Battery




## 8. CNX-107 Board




**Confidential**

## 9. Display Assy




## 10. Housing (Bezel) Assy



**Confidential**

## 11. Inverter Unit, ANL-24 Board, Microphone, LCD Assy



**Confidential**

### 2-1. Precautions

This self-diagnostic material summarizes the items to be checked and the self-tests to be performed using the main unit, FDD & CD-ROM drives, and port replicator.

### 2-2. Necessary Tools

- PCG-SR series main unit
- Floppy-disk drive
- CD-ROM drive
- Battery
- AC adaptor
- CD-ROM for self-diagnostics
- Floppy disk for self-diagnostics (Installs the DOS system.)
- Port replicator
- Other tools required for the tests

### 2-3. Starting up the Service Diagnostics

1. The service diagnostics floppy disk and CD disc are prepared for the respective models separately. Insert the service diagnostics floppy disk and CD disc of the desired model, then turn on the main power of the personal computer. The model information that is unique to your personal computer and is stored in ROM, is automatically read and appears on the test menu. If the wrong service diagnostics CD disc that does not support your personal computer is inserted, an error message is displayed.
2. The driver software is installed from the CD disc, the necessary ROM information is automatically read and the initial settings are made, then the following self-diagnostics menu appears.

```
***** Main Menu *****  
1:Check ROM Information...      c:Video test...  
2:Battery test...              d:PPK test...  
3:HDD test...                  e:GUID (IEEE1394) test...  
4:keyboard test...             f:IEEE1394 Interface test...  
5:LED test...                  j:IrDA test...  
6:Main memory test...          h:Jog dial test...  
7:Main system test...          i:Short aging test...  
8:FAN test...                  j:Long aging test...  
9:Touch pad test...            k:Aging test including the HDD test...  
a:Serial Loopback test...      l:Exit from Diagnostics MENU  
b:Parallel Loopback test...
```

3. When the service diagnostics ends with success, the message “Pass” appears. When it ends with failure, detecting an error, the message “Fail” appears. Press the “Esc” key to abort the self diagnostics.

## 2-4. Outline of Service Diagnostics Functions

- Check ROM Information...

Displays the model information, serial number, BIOS and other information saved in the BIOS ROM.

Does not test whether or not the personal computer is normal.

- Battery test...

Tests the battery, as to whether the battery is attached or removed, the main power is supplied from an AC power adapter or not, and the battery is charged or discharged. The test procedure appears on the display. Perform the battery test following the messages on display.

Remove and attach the battery → Check (Removal and attachment of battery)

Disconnect and connect the AC power → Check (Disconnection and connection of AC power)

Remove and attach the battery → Check (Discharge and charge of battery)

- HDD test...

Tests whether the HDD returns a response when communication is established with the hard disk drive. The HDD can be tested without damaging the HDD data (without formatting the HDD) in this test since the HDD data is tentatively stored in memory during the test.

If the main power is turned off by mistake while the test is under way, the HDD data can be damaged. The following tests are performed automatically.

1. HDD interface test (Tests whether or not the HDD is recognized)

2. HDD seek test

3. HDD read test

4. HDD write test

5. HDD random read test and random write test (It takes about 2 hours for the 18 GB HDD. This time is a guideline and changes depending on the model.)

6. Returns to the main menu.

- Keyboard test...

Tests the keyboard. When the “Auto select” menu is selected, the keyboard type in use is recognized from the model information that is written in ROM when shipped from the factory and the test is executed accordingly. When a specific keyboard type is selected such as US, UK, or JP, then the keyboard of the selected type is tested. If the model of your computer is JP and the keyboard type is replaced by either the US type or UK type keyboard, select the keyboard type after it is replaced.

**NOTE:** The “Fn” key can be checked by pressing the “Fn” and “→” keys at the same time. Other keys can be checked by pressing the respective keys.

- LED test...

Tests the LED. This test turns on one LED after another. The person conducting the test must visually check whether each LED is normal or not. The test starts from the front LEDs (from left to right). Then the LEDs in the center are checked (from left to right).

**NOTE:** The memory stick access test using the LED cannot be run on DOS. Run it on Windows.



- Main Memory test...

Tests the main memory. The Main Memory test contains the following three test menus. Select the menu that suits your need. The test is exited automatically when the respective test items end normally.

- Fast : Tests once. (Taking one and half minutes to two minutes)
- Medium : Test ten times.
- Heavy : Test twenty times.

Press the “Esc” key to abort the test.

- Main System test...

Tests the fundamental functions of the CPU, etc. The test is exited automatically when all test items end normally.

- FAN test...

Tests the fan. Tests whether the fan rotates and stops. Listen to the rotating sound or feel the wind of the fan to judge whether the fan rotates and stops. The test procedure appears on display. Perform the FAN test following the messages displayed. Press “Y” to resume rotation when the fan comes to stop. Press “Y” when the fan starts rotating, indicating that the test ends in success.

- Touch pad test...

Tests the touch pad. Tests whether the cursor moves, and whether right-clicking and left-clicking function properly. The dialog box appears three times. Move the cursor to the box that appears. The tests are performed in the following order.

- (1) Touch pad
- (2) Right-click button
- (3) Left-click button

- Serial loopback test...

The computer cannot perform this test.

- Parallel loopback test...

The computer cannot perform this test.

- Video test...

**NOTE:** Because this test is performed by visual inspection, confirm first the normal video picture, then start the test.

Tests the video signal. Several video patterns appear every time the key is pressed. The person conducting the test must visually check whether the patterns appear properly. Press Y when there is no abnormality.

- PPK test...

The computer cannot perform this test.

- GUID test...

This test is not normally required. Displays the GUID (I-link ID value), and judges whether the value on the display is appropriate.

- IEEE 1394 Interface test...

Performs the 1394 communication test. Another personal computer to communicate with is necessary for this test. The models released from the year 2000 have already been confirmed that they do not cause any problems regarding the IEEE1394 interface. Even models released before 2000 will cause no problem if the same type of IEEE1394 interface IC chip (the IC chip used in the iLink block connected to the PCI bus) is used in both personal computers that are connected. In other combinations, the IEEE1394 interface test is not confirmed. (Use of the models released from the year 2000 is recommended.)

1. Connect the iLink cable.
2. Start up the personal computer at the other end of the IEEE1394 interface test connection using the tool floppy disk. This must be created beforehand by copying programs from the service diagnostics CD disc. (Prepare a floppy disk that is formatted to contain the DOS system. Create a tool floppy disk by copying the entire TOOL folder of the CD disc to a floppy disk.)
3. Select the 1394 test from the menu at the connected computer to enter the reception state.
4. After the connected personal computer has entered the reception state, select the 1394 test at the personal computer to be tested. The IEEE1394 interface test then starts. Send and receive of the random data is repeated five times (i.e., this test is repeated five times.)

- IrDA test...

The computer cannot perform this test.

- Jog dial test...

Tests the revolution and clicking of the jog dial. Angle brackets <> appear when the jog dial test is selected. Rotate the jog dial clockwise (upwards) until it moves to the mark (^\_^) then press the jog dial. The mark (^\_^) appear will on the top of the screen. Then rotate the jog dial counter-clockwise (downwards) until it moves to the mark (^\_^) then press the jog dial.

- Short aging test.../Long aging test...

Performs the aging test. The short aging test ends when all test items have been performed once. The long aging test checks the machine for about 10 hours by repeating the test items.

- Aging test including the HDD...

**NOTE:** This test destroys the entire contents of the user's hard disk drive.

Perform this test only when destructive testing of HDD is desired.

The aging test is performed first, then read and write tests of the hard disk are implemented following the aging test. There are two tests; LONG and SHORT. Contents of the LONG aging test are the same as those the "Long aging test..." of the previous test item. Contents of the SHORT aging test are the same of the "Short aging test..." too. The test starts immediately when the menu item is selected.

- Exit from Diagnostics MENU

Quits the service diagnostics program and the DOS prompt appears. If you exit the service diagnostics program by mistake, start the program again.

## 2-5. *Inspecting Windows*

The Windows inspection contains the following two types of inspection.

Audio  
Modem

Before starting inspections, create a floppy disk from the service diag CD to be serviced.

The files to be used for inspection are stored in the following sub directory inside the CD. Copy all the files in the folder to the floppy disk.

Audio        \windiag\wave  
Modem        \windiag\modem

- Audio

A microphone and headphones are required for this inspection.

Double-click the “t\_auw01” icon (MS-DOS icon) on the floppy disk that has been created in advance. The display of the DOS prompt opens and the inspection starts. Once inspection starts, follow the instructions on the display to inspect the audio.

- Modem


A modem and a line simulator are required for this inspection.

Double-click the “modem” icon (MS-DOS icon) on the floppy disk that has been created in advance.

The display of the DOS prompt opens and the inspection starts.


**CHAPTER 3.**  
**BLOCK DIAGRAM**

*PCG-SR Series Block Diagram*



# CHAPTER 4.

## FRAME HARNESS DIAGRAM



# CHAPTER 5.

## EXPLODED VIEWS AND PARTS LIST


### NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- When two or more parts are shown in parallel, use the part described first as the main part.

The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  $\Delta$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


### 5-1. Main Section



Ref.No.	Part No.	Description
* 1	4-646-973-02	DUCT (L)
2	1-529-660-21	SPEAKER, (2.0CM)
4	4-644-492-31	ACE (M2X4), LOCK
5	4-644-492-51	ACE (M2X3.5), LOCK
6	X-4622-725-2	ESCUTCHEON (LF) ASSY
8	4-650-469-01	FOOT
9	X-4622-945-1	HOUSING (BOTTOM) (C) ASSY
10	4-650-608-01	LID (HEAT) (A)
14	4-647-207-01	BUSHING (FAN)
15	4-644-493-11	ACE (M2.6X4), LOCK
16	4-635-956-01	SPRING (B), COMPRESSION COIL
18	4-647-535-01	INSULATOR RJ-11
19	1-794-537-11	HARNESS, MODULAR
20	1-678-628-11	PWB, FLEXIBLE PRINT
21	1-678-659-11	FPC (HDD)
* 22	4-646-726-01	BRACKET (F)
23	1-792-890-11	FFC (MBX-34-CN9-96)
24	4-646-724-01	ESCUTCHEON (RF)
25	4-635-301-01	SCREW M3X4
26	1-772-727-11	HDD (DJSA-220 20.0GB)
27	A-8066-221-A	CNX-107 COMPL
28	X-4622-918-2	DIAL ASSY
29	4-644-492-01	ACE (M2), LOCK
31	4-647-547-01	BUSHING (PC BOARD)
32	A-8066-210-A	SWX-61 COMPL

Ref.No.	Part No.	Description
33	4-647-538-11	COOLING (1)
34	1-792-891-11	FFC (MBX-34-SWX-55)
35	4-648-320-01	TAPPING (M2)
36	1-529-660-31	SPEAKER, (2.0CM)
39	4-646-718-03	ESCUTCHEON (PAD)
40	1-772-529-21	PAD, TOUCH
41	1-792-893-11	FFC (SWX-55-TOUCH PAD)
42	4-646-814-01	WINDOW (JOG)
43	X-4622-697-3	HOUSING (PARM REST) ASSY
44	8-759-696-84	IC VANH64T
45	1-792-892-12	FFC (MBX-34-IFX-109)
46	4-648-140-11	SHEET (C), THERMAL
47	4-646-728-02	ESCUTCHEON (LB)
* 48	4-650-213-01	HEATSINK NT2
49	4-651-343-01	SHEET (NT2), THERMAL
51	1-794-553-11	CONNECTOR, PC CARD(EJECTOR)
52	A-8048-378-A	C/P MBX-44 (P3/700/X) (S)
53	1-528-984-11	BATTERY, V/L RECHARGEABLE
55	A-8066-217-A	IFX-124 COMPL
56	4-647-533-02	INSULATOR IFX-108
57	A-8066-215-A	DDC-3 COMPL
58	4-647-534-02	INSULATOR DDC-2
59	4-646-852-01	CLAMP
60	1-763-562-11	FAN, DC (UDQFSEH52)
61	X-4622-699-6	FRAME ASSY
62	4-648-125-01	ACE(M2 SPECIAL FLAT), LOCK
63	4-646-722-02	BLIND, SCREW
64	X-4622-724-3	ESCUTCHEON (RB) ASSY
65	4-647-168-02	CAP MODEM
66	1-476-148-23	KEY BOARD UNIT
68	4-651-383-01	SHEET (TOUCH PAT) (2)
69	4-646-713-01	BASE (L), FOOT
70	4-646-708-01	FOOT, REAR
71	4-646-725-03	BUTTON, POWER
73	4-647-181-11	HEX SCREW (MBX)
74	4-647-181-01	HEX SCREW (MBX)
* 75	4-646-732-01	BRACKET (B)
76	1-794-546-11	CONNECTOR, MEMORY STICK, EJECTOR
77	A-8066-212-A	IFX-125 COMPL
78	7-622-205-05	NUT M2 TYPE2
79	4-646-800-01	CUSHION (BB)
80	4-646-794-01	WINDOW (MS)
81	4-650-733-11	(SR17K)...LABEL ID (GZU)
81	4-650-735-11	(SR17)...LABEL ID (GU)
82	4-648-304-01	BLIND (PC BOARD)
* 83	4-646-719-01	HOLDER, SPEAKER
84	4-646-720-02	SHEET ICON
85	7-685-504-19	SCREW +BTP 2X6 TYPE2 N-S
88	4-648-819-01	COVER KEYBOARD
* 89	4-648-847-02	INSULATOR (DC JACK)
92	4-646-730-02	INSULATOR (MBX)
93	4-648-438-01	PLATE
94	4-649-669-01	CUSHION IFX
95	4-648-624-01	INSULATOR PC CARD
96	4-649-299-01	WOVEN (SP), FABRIC NON
97	4-651-347-01	FINGER (KEY BOARD)
98	4-650-959-01	SHEET (PARM), RADIATION
99	4-651-335-01	SHEET (BUTTON)
200	4-651-354-01	SHIELD MS
202	4-648-354-03	MS SEAT
203	7-621-772-30	SCREW +B 2X6


5-2. LCD Section – Made by TS –




Ref.No.	Part No.	Description
101	4-646-977-01	BLIND (LCD), SCREW
102	4-644-492-31	ACE (M2X4), LOCK
103	X-4622-698-2	HOUSING (BEZEL) ASSY
105	A-8045-747-A	LCD ASSY (S)
106	4-646-705-02	TUBE, TOP
108	4-646-703-01	KNOB (LATCH)
109	4-639-890-01	SCREW (+B M2.6X2.5)
111	4-646-704-02	LEVER (LATCH)
112	4-635-923-01	HOLDER (MICROPHONE)
113	1-542-402-21	MICROPHONE, ELECTRET CONDENSER
114	A-8066-208-A	ANL-24 COMPL
115	1-960-481-11	HARNESS, LCD
116	4-647-547-01	BUSHING (PC BOARD)
117	4-639-623-11	SPRING (LATCH), COIL
118	4-644-493-11	ACE (M2.6X4), LOCK
119	4-646-791-11	TILT (L)
120	4-646-706-01	COVER (L)
123	4-646-792-11	TILT (R)
124	1-418-085-41	INVERTER UNIT
125	4-646-722-02	BLIND, SCREW
126	4-646-700-01	COVER (R)
127	4-647-482-02	SEAL (LVDS)
128	X-4622-700-1	HOUSING (DISPLAY) ASSY
129	4-646-975-01	BUSHING
130	4-646-976-02	CUSHION (LATCH)
131	4-648-793-01	WASHER (LATCH)
132	4-648-451-01	SPACER
133	7-621-772-00	SCREW +B 2X3

Ref.No.	Part No.	Description
		ACCESSORIES *****
△ 301	1-476-163-11	ADAPTOR, AC
302	1-756-100-21	BATTERY PACK, LITHIUM ION (L)
	1-757-026-11	CABLE, VGA
△	1-782-614-11	CORD, POWER
	4-650-752-11	WELCOM MAT SR
	4-650-685-11	QUICK START SR
	4-650-790-11	USER GUIDE SR

301  
Adaptor AC



302  
Battery Pack



The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
--	--